




# INSTALLATION & SERVICING

**LOGIC MAX SYSTEM<sup>2</sup>**  
**S15 S18 S24 S30**

When replacing any part on this appliance, use only spare parts that you can be assured conform to the safety and performance specification that we require. Do not use reconditioned or copy parts that have not been clearly authorised by Ideal Heating. For the very latest copy of literature for specification and maintenance practices visit our website [idealheating.com](http://idealheating.com) where you can download the relevant information in PDF format.



## ERP DATA

|                                          | SYMBOL      | UNITS        | MODEL  |       |       |       |    |
|------------------------------------------|-------------|--------------|--------|-------|-------|-------|----|
|                                          |             |              | 15 kW  | 18 kW | 24 kW | 30 kW |    |
| Condensing Boiler                        | n/a         | n/a          | yes    | yes   | yes   | yes   |    |
| Low Temperature Boiler                   | n/a         | n/a          | no     | no    | no    | no    |    |
| B1 Boiler                                | n/a         | n/a          | no     | no    | no    | no    |    |
| Cogeneration Space Heater                | n/a         | n/a          | no     | no    | no    | no    |    |
| Equipped with a Supplementary Heater     | n/a         | n/a          | no     | no    | no    | no    |    |
| Combination Heater                       | n/a         | n/a          | no     | no    | no    | no    |    |
| Nominal Heat Output for Space Heating    |             |              |        |       |       |       |    |
| Full Load                                | P4          | kW           | 15.1   | 18.1  | 24.3  | 30.3  |    |
| Part Load                                | P1          | kW           | 4.9    | 5.9   | 8.0   | 9.9   |    |
| Auxiliary Electricity Consumption        |             |              |        |       |       |       |    |
| Full Load                                | elmax       | kW           | 0.020  | 0.025 | 0.044 | 0.052 |    |
| Part Load                                | elmin       | kW           | 0.003  | 0.023 | 0.012 | 0.012 |    |
| Standby                                  | PSB         | kW           | 0.002  | 0.002 | 0.002 | 0.001 |    |
| Seasonal Space Heating Energy Efficiency |             |              |        |       |       |       |    |
| Full Load                                | η4          | %            | 90.0   | 90.0  | 90.0  | 89.6  |    |
| Part Load                                | η1          | %            | 97.8   | 98.5  | 98.6  | 98.2  |    |
| Standby Loss                             | Pstby       | kW           | 0.05   | 0.05  | 0.05  | 0.05  |    |
| Ignition                                 | Pign        | kW           | 0      | 0     | 0     | 0     |    |
|                                          |             |              |        |       |       |       |    |
| Emissions                                | NOx (Gross) | NOx, pond Hs | mg/kWh | 21    | 24    | 28    | 26 |
| Annual Energy Consumption                | QHE         | GJ           | 47     | 56    | 75    | 93    |    |
| Sound Power Level, Indoors               | LWA         | dB           | 42     | 44    | 50    | 50    |    |




**WEEE DIRECTIVE 2012/19/EU**  
**Waste Electrical and Electronic Equipment Directive**

- At the end of the product life, dispose of the packaging and product in a corresponding recycle centre.
- Do not dispose of the unit with the usual domestic refuse.
- Do not burn the product.
- Remove the batteries.
- Dispose of the batteries according to the local statutory requirements and not with the usual domestic refuse.



The code of practice for the installation, commissioning & servicing of central heating systems



# PRODUCT FICHE

## LOGIC MAX SYSTEM<sup>2</sup> S BOILER

Ideal Heating ERP DATA

|                                          | SYMBOL   | UNITS | MODEL |       |       |       |
|------------------------------------------|----------|-------|-------|-------|-------|-------|
|                                          |          |       | 15 kW | 18 kW | 24 kW | 30 kW |
| Condensing boiler                        |          |       | Yes   |       |       |       |
| Seasonal space heating efficiency class  |          |       | A     |       |       |       |
| Rated heat output                        |          | kW    | 15    | 18    | 24    | 30    |
| Seasonal space heating energy efficiency | $\eta_s$ | %     | 93    | 93    | 94    | 93    |
| Annual energy consumption                | $Q_{HE}$ | GJ    | 47    | 56    | 75    | 93    |
| Sound power level, indoors               | LWA      | dB    | 42    | 44    | 50    | 50    |

|                                                         |          |           |          |         |          |           |            |                    |   |
|---------------------------------------------------------|----------|-----------|----------|---------|----------|-----------|------------|--------------------|---|
| Seasonal Space Heating Energy Efficiency of the Boiler  |          |           |          |         |          |           |            | 94% <sup>***</sup> | A |
| Temperature control (from fiche of temperature control) |          |           |          |         |          |           |            |                    | B |
| Class I                                                 | Class II | Class III | Class IV | Class V | Class VI | Class VII | Class VIII |                    |   |
| 1%                                                      | 2%       | 1.5%      | 2%       | 3%      | 4%       | 3.5%      | 5%         |                    |   |

### Solar Contribution (from fiche of solar device)

Collector Size  
(in m<sup>2</sup>)

Tank Volume  
(in m<sup>3</sup>)

Collector Efficiency  
(in %)

Tank rating  
 A\* = 0.95  
 A = 0.91  
 B = 0.86  
 C = 0.83  
 D-G = 0.81

$$= ('III' \times \boxed{\phantom{00}} + 'IV' \times \boxed{\phantom{00}}) \times 0.9 \times (\boxed{\phantom{00}} / 100 \times \boxed{\phantom{00}}) = \boxed{\phantom{00}}\%$$

C

Seasonal Space Heating Energy Efficiency of Package

TOTAL: A+B+C=

%

### Seasonal Space Heating Energy Efficiency Class of Package

|       |       |       |       |       |       |       |       |        |        |
|-------|-------|-------|-------|-------|-------|-------|-------|--------|--------|
|       |       |       |       |       |       |       |       |        |        |
| G     | F     | E     | D     | C     | B     | A     | A+    | A++    | A+++   |
| < 30% | ≥ 30% | ≥ 34% | ≥ 36% | ≥ 75% | ≥ 82% | ≥ 90% | ≥ 98% | ≥ 125% | ≥ 150% |

The energy efficiency of the package of products provided for in this document may not correspond to its actual energy efficiency once installed in a building, as the efficiency is influenced by further factors such as heat loss in the products in relation to the building size and its characteristics

## NOTES FOR THE INSTALLER

For any technical queries please ring the Ideal installer helpline : 01482 498663

### **BOILER RESTART PROCEDURE -**

**Press the RESTART button. The boiler will repeat the ignition sequence if a heat demand is present.**

## DEFINITIONS



**WARNING:** Risk of injury or death



**CAUTION:** Risk of damage to objects



**IMPORTANT:** Important information

## Table of Acronyms

**CH** - Central Heating

**DHW** - Domestic Hot Water

**TRV** - Thermostatic Radiator Valve

**PRV** - Pressure Relief Valve

**IE** - Ireland

**ETCI** - Electro-Technical Council of Ireland

**BS** - British Standard

**WRAS** - Water Regulations Advisory Scheme

**SAP** - Standards Assessment Procedure

**IEE** - Institution of Electrical Engineers

**UKCA** - UK Conformity Assessed

**RHS** - Right Hand Side

**LHS** - Left Hand Side

**PCB** - Printed Circuit Board

# CONTENTS

|                                                    |    |                                                                  |    |
|----------------------------------------------------|----|------------------------------------------------------------------|----|
| Section 1 - General.....                           | 6  | Section 3 - Servicing.....                                       | 35 |
| 1.1 Introduction.....                              | 8  | 3.1 Servicing Schedule.....                                      | 35 |
| 1.2 Operation.....                                 | 8  | 3.2 Removal / Replacement of Components.....                     | 36 |
| 1.3 Safe Handling.....                             | 8  | 3.3 Draining the Boiler.....                                     | 36 |
| 1.4 Optional Accessories.....                      | 8  | 3.4 Boiler Front Panel Removal / Replacement.....                | 37 |
| 1.5 Safety.....                                    | 8  | 3.5 Flue Manifold Removal/Replacement.....                       | 37 |
| 1.6 Safe Handling of Substances.....               | 9  | 3.6 Fan and Venturi Assembly Removal and Cleaning.....           | 38 |
| 1.7 Location of Boiler.....                        | 9  | 3.7 Burner Removal and Cleaning.....                             | 39 |
| 1.8 Air Supply.....                                | 10 | 3.8 Cleaning the Heat Exchanger.....                             | 39 |
| 1.9 Gas Supply.....                                | 10 | 3.9 Ignition / Detection Electrode Replacement / Inspection..... | 40 |
| 1.10 Water Circulation System.....                 | 10 | 3.10 Cleaning the Condensate Trap.....                           | 40 |
| 1.11 Boiler Controls.....                          | 10 | 3.11 External System Filter Cleaning Guide.....                  | 41 |
| 1.12 Electrical Supply.....                        | 10 | 3.12 Burner Injector Replacement.....                            | 41 |
| 1.13 Condensate Drain.....                         | 10 | 3.13 Burner Replacement.....                                     | 41 |
| 1.14 Boiler Dimensions, Services & Clearances..... | 11 | 3.14 Return Thermistor Replacement.....                          | 41 |
| 1.15 System Requirements - Central Heating.....    | 12 | 3.15 Spark Generator Replacement.....                            | 42 |
| 1.16 System Balancing.....                         | 13 | 3.16 Gas Control Valve Replacement.....                          | 42 |
| 1.17 Water Treatment.....                          | 13 | 3.17 Condensate Trap Replacement / Cleaning.....                 | 42 |
| Section 2 - Installation.....                      | 14 | 3.18 Pressure Gauge Replacement.....                             | 43 |
| 2.1 Boiler Assembly - Exploded View.....           | 14 | 3.19 PRV Replacement.....                                        | 43 |
| 2.2 Unpacking.....                                 | 15 | 3.20 Primary PCB Replacement.....                                | 44 |
| 2.3 Wall Mounting Template.....                    | 16 | 3.21 Pump Automatic Air Vent Replacement.....                    | 45 |
| 2.4 Preparing the Wall.....                        | 16 | 3.22 Pump Head Replacement.....                                  | 45 |
| 2.5 Fitting the Wall Mounting Plate.....           | 16 | 3.23 CH Water Pressure Switch Replacement.....                   | 46 |
| 2.6 Mounting the Boiler.....                       | 16 | 3.24 Flow Thermistor Replacement.....                            | 46 |
| 2.7 Flues and Locations.....                       | 17 | 3.25 Expansion Vessel Recharging & Replacement.....              | 47 |
| 2.8 Flues and Locations - Continued.....           | 18 | 3.26 Heat Engine Replacement.....                                | 48 |
| 2.9 Horizontal Flue Positions.....                 | 19 | Section 4 - Fault Finding.....                                   | 49 |
| 2.10 Vertical Flue Positions.....                  | 19 | 4.1 Main Menu, Fault Help.....                                   | 49 |
| 2.11 Flue System Dimensions.....                   | 20 | 4.2 Overheat Lockout.....                                        | 49 |
| 2.12 Fitting the Turret.....                       | 20 | 4.3 Ignition Lockout.....                                        | 50 |
| 2.13 Cutting the Flue.....                         | 21 | 4.4 Flame On Before Gas Valve On.....                            | 50 |
| 2.14 Assembling the Vertical Flue.....             | 22 | 4.5 Low Water Pressure.....                                      | 50 |
| 2.15 Condensate Drain.....                         | 23 | 4.6 Flame Loss.....                                              | 51 |
| 2.16 Condensate Drain - Continued.....             | 24 | 4.7 Fan Fault.....                                               | 51 |
| 2.17 Connections & Filling.....                    | 25 | 4.8 Flow Thermistor Fault.....                                   | 52 |
| 2.18 Electrical Connections.....                   | 25 | 4.9 Return Thermistor Fault.....                                 | 52 |
| 2.19 Installer Wiring.....                         | 26 | 4.10 Outside Sensor Fault.....                                   | 53 |
| 2.20 Installer Wiring Continued.....               | 27 | 4.11 No CH Operation.....                                        | 53 |
| 2.21 Replacing Pre-fitted Mains Cable.....         | 27 | 4.12 No DHW Operation.....                                       | 54 |
| 2.22 Electrical Controls.....                      | 27 | 4.13 No Display.....                                             | 54 |
| 2.23 Wiring Diagram.....                           | 28 | Section 5 - Spare Parts.....                                     | 55 |
| 2.24 Commissioning and Testing.....                | 29 | Section 6 - Benchmark & Commissioning.....                       | 56 |
| 2.25 Initial Lighting.....                         | 30 |                                                                  |    |
| 2.26 User Interface Commissioning.....             | 31 |                                                                  |    |
| 2.27 Changing Boiler Operating Mode.....           | 31 |                                                                  |    |
| 2.28 Menu Operation.....                           | 32 |                                                                  |    |
| 2.29 Maximum and Minimum Rates.....                | 32 |                                                                  |    |
| 2.30 General Checks.....                           | 33 |                                                                  |    |
| 2.31 Restart Procedure.....                        | 34 |                                                                  |    |
| 2.32 Handing Over.....                             | 34 |                                                                  |    |

## Section 1 - General

**Table 1 General Data**

|                                           |                             | 15 kW                                  | 18 kW        | 24 kW         | 30 kW         |
|-------------------------------------------|-----------------------------|----------------------------------------|--------------|---------------|---------------|
| Gas Supply                                |                             | 2H-G20 - 20 mbar                       |              |               |               |
| Gas Supply Connection                     |                             | 15 mm copper compression               |              |               |               |
| Injector Size                             | mm                          | 4.15                                   | 4.15         | 4.15          | 4.65          |
| Flow Connection                           | Central Heating             | 22 mm copper compression               |              |               |               |
| Return Connection                         | Central Heating             | 22 mm copper compression               |              |               |               |
| Flue Terminal Diameter                    | mm                          | 100                                    |              |               |               |
| Average Flue Temp-Mass Flow Rate          |                             | 56°C - 6 g/s                           | 58°C - 8 g/s | 63°C - 10 g/s | 69°C - 13 g/s |
| CO <sub>2</sub> Content (± 0.7)           | Max. CH                     | 9.5%                                   | 9.3%         | 9.2%          | 9.6%          |
|                                           | Min. CH                     | 8.9%                                   | 8.3%         | 8.5%          | 8.7%          |
| Maximum Working Pressure (Sealed Systems) | bar (psi)                   | 2.5 (36.3)                             |              |               |               |
| Electrical Supply                         |                             | 230 V ~ 50 Hz                          |              |               |               |
| Power Consumption                         | W                           | 70                                     | 75           | 94            | 102           |
| Fuse Rating                               |                             | External: 3A Internal : T4A HRC L250 V |              |               |               |
| Water Content                             | Central Heating litre (gal) | 1.2 (0.26)                             |              |               |               |
| Packaged Weight                           | kg                          | 33.2                                   |              |               |               |
| Lift Weight                               | kg                          | 27.3                                   |              |               |               |
| Boiler Casing Size                        | Height mm                   | 700                                    |              |               |               |
|                                           | Width mm                    | 395                                    |              |               |               |
|                                           | Depth mm                    | 278                                    |              |               |               |

**Table 2 Performance Data - Central Heating**

| Boiler Input:                                                  |          | 15 kW   |       | 18 kW |       | 24 kW |       | 30 kW |       |
|----------------------------------------------------------------|----------|---------|-------|-------|-------|-------|-------|-------|-------|
|                                                                |          | Min     | Max   | Min   | Max   | Min   | Max   | Min   | Max   |
| Boiler ‘Q’<br>Net CV                                           | kW       | 4.9     | 15.1  | 4.9   | 18.1  | 4.9   | 24.3  | 6.1   | 30.4  |
|                                                                | Gross CV | kW      | 5.4   | 16.6  | 5.4   | 20.1  | 5.4   | 27.0  | 6.7   |
| Gas Consumption                                                | m³/h     | 0.500   | 1.537 | 0.500 | 1.872 | 0.500 | 2.512 | 0.623 | 3.136 |
| Boiler Output :<br><br>Non Condensing 70°C Mean<br>Water Temp. | kW       | 4.8     | 15.0  | 4.8   | 18.0  | 4.8   | 24.2  | 6.1   | 30.3  |
| Condensing<br>40°C Mean Water Temp.                            | kW       | 5.1     | 15.9  | 5.1   | 19.1  | 5.1   | 25.6  | 6.4   | 31.0  |
| Seasonal Efficiency* SEDBUK 2005                               |          | 91.2%   |       | 91.1% |       | 91.2% |       | 91.1% |       |
| Seasonal Efficiency* SEDBUK 2009/2012                          |          | 89.4%   |       | 89.7% |       | 89.7% |       | 89.6% |       |
| NOx Classification                                             |          | Class 6 |       |       |       |       |       |       |       |

\* The value is used in the UK Government's Standard Assessment Procedure (SAP) for energy rating of dwellings.

The test data from which it has been calculated, has been certified by a notified body.

Gas consumption is calculated using a calorific value of 38.7 MJ/m<sup>3</sup> (1038 Btu/ft<sup>3</sup>) gross or 34.9 MJ/m<sup>3</sup> (935 Btu/ft<sup>3</sup>) nett

To obtain the gas consumption at a different calorific value:

- For l/s - divide the gross heat input (kW) by the gross C.V. of the gas (MJ/m<sup>3</sup>)
- For Btu/h - multiply the gross heat input (kW) by 26.8
- For ft<sup>3</sup>/h - divide the gross heat input (Btu/h) by the gross C.V. of the gas (Btu/ft<sup>3</sup>)
- For m<sup>3</sup>/h - multiply l/s by 3.6


**C13 C33 C53** = A room sealed appliance designed for connection via ducts to a horizontal or vertical terminal, which admits fresh air to the burner and discharges the products of combustion to the outside through orifices which, in this case, are concentric. The fan is up stream of the combustion chamber.

**I<sub>2H</sub>** = An appliance designed for use on 2nd family gas, Group H only.

**II<sub>2H/3P</sub>** = An appliance designed for use on 2nd or 3rd family gases, Group H or P.

**LOGIC MAX SYSTEM<sup>2</sup> S****Natural Gas Only**

| BOILER SIZE<br>kW | G.C. Appliance No<br>(Benchmark No.) |
|-------------------|--------------------------------------|
| 15                | 41-796-97                            |
| 18                | 41-796-98                            |
| 24                | 41-796-99                            |
| 30                | 41-860-01                            |

**Destination Country:** UK

For UK, to comply with Building Regulations Part L1 (Part 6 in Scotland) the boiler should be fitted in accordance with the manufacturer's instructions. Self-certification that the boiler has been installed to comply with Building Regulations can be demonstrated by completing and signing the Benchmark Commissioning Checklist.

Before installing this boiler, read the Code of Practice sheet at the rear of this book.

**BENCHMARK COMMISSIONING CHECKLIST DETAILS**

| <b>Boiler</b>                                   | <b>Page</b>      |                                      | <b>Page</b>                                       |
|-------------------------------------------------|------------------|--------------------------------------|---------------------------------------------------|
| Make and model.....                             | 7                | Burner operating pressure .....      | n/a                                               |
| Appliance serial no. on data badge .....        | Front Cover      | Central heating flow temp. ....      | measure and record                                |
| SEDBUK No. %.....                               | 6                | Central heating return temp. ....    | measure and record                                |
| <b>Controls</b>                                 |                  | <b>For combination boilers only</b>  |                                                   |
| Time and temperature control to heating .....   | 27               | Scale reducer .....                  | 13                                                |
| Time and temperature control to hot water ..... | 27               | <i>Hot water mode</i>                |                                                   |
| Heating zone valves.....                        | n/a              | Heat input.....                      | to be calculated                                  |
| TRVs .....                                      | 10               | Max. operating burner pressure ..... | n/a                                               |
| Auto bypass .....                               | 10               | Max. operating water pressure.....   | measure & record                                  |
| Boiler interlock.....                           | 10               | Cold water inlet temp .....          | measure & record                                  |
| <b>For all boilers</b>                          |                  | Hot water outlet temp .....          | measure & record                                  |
| Flushing to BS.7593.....                        | 13               | Water flow rate at max. setting..... | measure & record                                  |
| Inhibitor .....                                 | 13               | <b>For condensing boilers only</b>   |                                                   |
| <i>Central heating mode</i>                     |                  | Condensate drain.....                | 23-24                                             |
| Heat input.....                                 | to be calculated | <b>For all boilers:</b>              | <i>Complete, sign &amp; hand over to customer</i> |

NOTE TO THE INSTALLER: COMPLETE THE BENCHMARK COMMISSIONING CHECKLIST  
AND LEAVE THESE INSTRUCTIONS WITH APPLIANCE



For assistance call  
Technical Helpline  
01482 498663

## Section 1 - General

### 1.1 INTRODUCTION

The **Logic Max System<sup>2</sup> S** range of boilers are wall mounted, full sequence, automatic spark ignition, low water content, fanned flue, high efficiency, condensing, system gas boilers.

Due to the high efficiency of the boiler a plume of water vapour will form at the terminal during operation.

The boiler is supplied fully assembled with circulating pump, pressure gauge, PRV and CH expansion vessel.

A variable CH temperature control is fitted on the user control.

The boiler includes as standard:

- Boiler Automatic bypass
- Boiler frost protection
- Daily pump exercise.

The boiler casing is of white painted mild steel with a white polymer front panel.

The boiler temperature controls are visibly located in the control panel on the front of the boiler.

The heat exchanger is manufactured from cast aluminium.

The boiler is suitable for connection to fully pumped, sealed heating systems **ONLY**. Adequate arrangements for completely draining the system by provision of drain cocks **MUST** be provided in the installation pipework.

Pipework from the boiler is routed downwards.

A PRV grommet is fitted to the boiler which requires the correct fitting and securing of a clip (supplied) to ensure safe discharge of the PRV should this occur.

The Ideal System filter is supplied with this boiler. Installation instructions for this are located within the system filter box.

Be sure to follow Ideal System filter installation and maintenance guide for correct method of installation. Failure to install the system filter correctly will affect boiler warranty.

#### Data Plate

The boiler model and serial number can be located on the bottom of the boiler casing, shown in Section 1.14 - Water & Gas Connection Diagram.

### 1.2 OPERATION

When there is a demand the system is supplied at the selected temperature of between 30°C and 80°C.

The boiler features a comprehensive diagnostic system which gives detailed information on the boiler status when operating, and performance of key components to aid commissioning and fault finding.

### 1.3 SAFE HANDLING

This boiler may require 2 or more operatives to move it to its installation site, remove it from its packaging base and during movement into its installation location. Manoeuvring the boiler may include the use of a sack truck and involve lifting, pushing and pulling.

Caution should be exercised during these operations.

Operatives should be knowledgeable in handling techniques when performing these tasks and the following precautions should be considered:

- Grip the boiler at the base.
- Be physically capable.
- Use personal protective equipment as appropriate, e.g. gloves, safety footwear.

During all manoeuvres and handling actions, every attempt should be made to ensure the following unless unavoidable and/or the weight is light.

- Keep back straight.
- Avoid twisting at the waist.
- Avoid upper body/top heavy bending.
- Always grip with the palm of the hand.
- Use designated hand holds.
- Keep load as close to the body as possible.
- Always use assistance if required.

### 1.4 OPTIONAL ACCESSORIES

Please visit [idealheating.com](http://idealheating.com) to access the optional accessories for this boiler.



### 1.5 SAFETY

#### Current Gas Safety (installation and use) regulations or rules in force:

The appliance is suitable only for installation in UK and should be installed in accordance with the rules in force.

In UK, the installation must be carried out by a Gas Safe Registered Engineer. It must be carried out in accordance with the relevant requirements of the:

- Gas Safety (Installation and Use) Regulations
- Appropriate Building Regulations, either The Building Regulations, The Building Regulations (Scotland), Building Regulations (Northern Ireland).
- Water Fittings Regulations or Water byelaws in Scotland.
- Current I.E.E. Wiring Regulations.

Where no specific instructions are given, reference should be made to the relevant British Standard Code of Practice.

## Section 1 - General

The Boiler has been tested and certified to:

BSEN 15502-1, BSEN 15502-2, BSEN 15502-2-1, BSEN 60335-1, BSEN 60335-2-102, BSEN 55014-1 and BSEN55014-2 for use with Natural Gas & Propane.

Detailed recommendations are contained in the following British Standard Codes of Practice:

- BS5440:1** Flues (for gas appliances of rated input not exceeding 70 kW).
- BS5440:2** Ventilation (for gas appliances of rated input not exceeding 70 kW).
- BSEN12828** Heating Systems in buildings: Design for water based heating systems.
- BSEN12831** Heating Systems in buildings: Method for calculation of the design heat load.
- BSEN14336** Heating Systems in buildings: Installation and commissioning of water based heating systems.
- BS5546** Installation of gas hot water supplies for domestic purposes (2nd Family Gases)
- BS6798** Installation of gas fired hot water boilers of rated input not exceeding 70 kW.
- BS6891** Installation and maintenance of low pressure gas installation pipework.
- BS 7593:2019** Code of practice for the preparation, commissioning and maintenance of domestic central heating and cooling water systems.

**Health & Safety Document No. 635.**

**The Electricity at Work Regulations, 1989.**

The manufacturer's notes must NOT be taken, in any way, as overriding statutory obligations.

**! IMPORTANT:** This appliance is UKCA/CE certificated for safety and performance. Do not connect external control devices directly to this appliance unless recommended in this manual or by **Ideal Heating** in writing. If in doubt, please enquire.

Unapproved control devices could invalidate the warranty of this appliance and infringe the Gas Safety Regulations.

## 1.6 SAFE HANDLING OF SUBSTANCES

No asbestos, mercury or CFCs are included in any part of the boiler or its manufacture.

## 1.7 LOCATION OF BOILER

The boiler must be installed on a flat and vertical internal wall, capable of adequately supporting the weight of the boiler and any ancillary equipment.

The boiler may be fitted on a combustible wall and insulation between the wall and the boiler is not necessary, unless required by the local authority.

### Timber Framed Buildings

Boilers installed in a timber-framed building must comply with IGE/UP7 +A 2008.


### Bathroom Installations



**CAUTION:** This appliance is IP20 rated, do not clean with jets of water.

You may install the boiler in any internal space. The installation must comply with the current IEE (BS 7671) Wiring Regulations and the electrical regulations applicable in Scotland.

If the appliance is to be installed in a room containing a bath or shower then, the appliance must be installed beyond Zone 2, as detailed in BS7671.



### Bathroom Installations

[0] Zone 0

[1] Zone 1

[2] Zone 2

[2\*] Without the end wall, zone 2 must extend 600 mm from the bath

[A] 600 mm radius from the bath or shower

### Compartment Installations

A boiler installed in a compartment does not require ventilation. However, A boiler installed in a compartment must provide adequate clearances for servicing.

The compartment should also be fitted with a suitable label in accordance with current standards.

Refer to Section  
1.14



**WARNING:** Rear access to the boiler is not permitted.



**CAUTION:** Do not fit the boiler outside.

## 1.8 AIR SUPPLY

It is not necessary to have an air vent in the room or internal space where the boiler is installed.

## 1.9 GAS SUPPLY

Consult the local gas supplier to establish an adequate supply of gas. Do not use existing service pipes without consulting the local gas supplier.

The gas supply must be governed with a meter.

A gas meter can only be connected by the local gas supplier or by a Gas Safe Registered Engineer.

An existing meter should be checked, preferably by the gas supplier, to ensure that the meter is adequate to deal with the required gas supply rate.

It is the responsibility of the Gas Installer to size the gas installation pipework in accordance with BS6891.

Whilst the principle of the 1:1 gas valve ensures the Logic range is able to deliver it is full output at inlet pressures as low as 14 mb, other gas appliances in the property may not be as tolerant. When operating pressures are found to be below the minimum meter outlet of 19 mb these should be checked to ensure this is adequate for correct and safe operation.

Allowing for the acceptable pressure loss of 1mb across the installation pipework, it can be assumed that a minimum permitted operating pressure of 18mb will be delivered to the inlet of the appliance.


(Reference BS6400-1 Clause 6.2 Pressure Absorption).

The external gas cock could further reduce the operating pressure when measured at its test point. The pressure drop is relative to the heat input to the boiler (kW), refer to graph below.

**IMPORTANT:** Ensure all gas valve connections are gas tight with a gas soundness check up to the gas control valve.

Installation pipes must be fitted in accordance with BS6891.

The complete installation MUST be tested for gas tightness and purged as described, for the majority of installations the appropriate standard is IGEM/UP/1B [23], but alternatively IGEM/UP/1 [21] or IGEM/UP/1A [22], as appropriate, can be utilized.



## 1.10 WATER CIRCULATION SYSTEM

**IMPORTANT:** A minimum length of 1 metre of copper pipe MUST be fitted to both flow and return connections from the boiler before connection to any plastic piping.

The central heating system should be in accordance with BS6798 and, in addition, for smallbore and microbore systems, BS5449.

Water treatment is covered later in these instructions.

Refer to Section  
1.17

## 1.11 BOILER CONTROLS

System controls should be installed to ensure the boiler has no demand when there is no requirement from the system, in compliance with Building Regulations.

Heating systems utilising full thermostatic radiator valve control of temperature in individual rooms should also be fitted with a room thermostat controlling the temperature in a space served by radiators not fitted with such a valve.

When thermostatic radiator valves are used, the space heating temperature control over a living / dining area or hallway having a heating requirement of at least 10% of the minimum boiler heat output should be achieved using a room thermostat, whilst other rooms are individually controlled by thermostatic radiator valves. However, if the system employs thermostatic radiator valves on all radiators, or two port valves, then a bypass circuit must be fitted with an automatic bypass valve to ensure a flow of water should all valves be in the closed position.

## 1.12 ELECTRICAL SUPPLY



**WARNING:** This appliance must be earthed

Wiring external to the appliance MUST be in accordance with the current I.E.E. (BS7671) Wiring Regulations and any local regulations which apply.

The mains supply to the boiler and system wiring centre shall be through one common fused double pole isolator and for new heating systems, and where practical replacement installations, the isolator shall be situated adjacent to the appliance.

## 1.13 CONDENSATE DRAIN

The condensate drain provided must be connected to the drainage point on site. All condensate drainage pipework and fittings must be made of plastic.

**IMPORTANT:** The condensate drain pipework should be installed in accordance with BS6798.

The drain outlet on the boiler is sized for standard 21.5 mm overflow pipe. It is a universal fitting to allow use of different brands of pipework.

Refer to Section  
2.15

## 1.14 BOILER DIMENSIONS, SERVICES & CLEARANCES

Refer to Section  
2.17

The boiler connections are made on the boiler connection tails.


**The following minimum clearances must be maintained for operation and servicing.**

Additional space will be required for installation, depending upon site conditions.


### Side and Rear Flue

- Provided that the flue hole is cut accurately, e.g. with a core drill, the flue can be installed from inside the building where wall thicknesses do not exceed 600 mm.


Measurements shown in mm



Water and Gas Connections



Underside View



### Front Clearance

The minimum front clearance when built in to a cupboard is 5 mm from the cupboard door but 450 mm overall clearance is still required, with the cupboard door open, to allow for servicing.

### \* Bottom Clearance

Bottom clearance after installation can be reduced to 15 mm. This must be obtained with an easily removable panel to provide the 100 mm clearance required for servicing. For easy access to the pressure gauge a bottom clearance of 15 mm is required for a partial open door.

### PRV Grommet

Refer to Section  
2.17

**IMPORTANT:** Please ensure there is sufficient clearance either side and below the boiler, particularly from door hinges and the base of a cupboard, to allow the door to be opened to allow the pressure gauge to be checked. Also ensure there is sufficient access to the system filter for draining, cleaning and dosing. For guidance please see Ideal System Filter Installation Manual.

## 1.15 SYSTEM REQUIREMENTS - CENTRAL HEATING

- The method of filling, refilling, topping up or flushing sealed primary hot water circuits from the mains via a temporary hose connection is only allowed if acceptable to the local water authority.
- Antifreeze fluid, corrosion and scale inhibitor fluids suitable for use with boilers having aluminium heat exchangers may be used in the central heating system.

### General

- The installation must comply with all relevant national and local regulations.
- Design the system for flow temperatures up to 80°C.
- The system components must be suitable for an operating pressure of 3 bar and a maximum temperature of 110°C.  
The following components are incorporated within the appliance:
  - Circulating pump.
  - PRV, with a non-adjustable preset lift pressure of 3 bar.
  - Pressure gauge, covering a range of 0 to 4 bar.
  - An 8 litre expansion vessel, with an initial charge pressure of 0.75 bar.

- Makeup Water.** One of the following provisions must be made for replacing system water loss:
  - Manually filled vessel  
The vessel must:  
Have a visible water level  
Be mounted at least 150 mm above the system's highest point  
Connect through a non-return valve to the system  
Be at least 150 mm below the makeup vessel on the return side of the radiators

- System prepressurisation.

The efficiency of the expansion vessel will be reduced in a pressurised system; a larger vessel or smaller system volume may be necessary.  
If the vessel's capacity is not sufficient, an additional vessel must be installed on the return to the boiler.  
If the system is not pressurised, the cold water capacity must not exceed 143 litres.

Guidance on vessel sizing is given in table above.




Table 3 Vessel Sizing

|                                                        |                                  |             |       |
|--------------------------------------------------------|----------------------------------|-------------|-------|
| PRV setting                                            | bar                              | 3.0         |       |
| Vessel charge pressure                                 | bar                              | 0.5 to 0.75 |       |
| System pre-charge pressure                             | bar                              | None        | 1.0   |
| System volume (litres)                                 | Expansion vessel volume (litres) |             |       |
|                                                        | 25                               | 1.6         | 1.8   |
|                                                        | 50                               | 3.1         | 3.7   |
|                                                        | 75                               | 4.7         | 5.5   |
|                                                        | 100                              | 6.3         | 7.4   |
|                                                        | 125                              | 7.8         | 9.2   |
|                                                        | 150                              | 9.4         | 11.0  |
|                                                        | 175                              | 10.9        | 12.9  |
|                                                        | 190                              | 11.9        | 14.0  |
|                                                        | 200                              | 12.5        | 14.7  |
|                                                        | 250                              | 15.6        | 18.4  |
|                                                        | 300                              | 18.8        | 22.1  |
| For other system volumes multiply by the factor across |                                  | 0.063       | 0.074 |

| Model                     |                     | 15            | 18            | 24            | 30            |
|---------------------------|---------------------|---------------|---------------|---------------|---------------|
| Max CH uuput              | kW                  | 15            | 18            | 24.2          | 30.3          |
| Water flow rate           | l/min<br>(gal/min)  | 10.7<br>(2.4) | 13<br>(2.8)   | 17.2<br>(3.8) | 21.5<br>(4.7) |
| Temp differential         | °C                  | 20            | 20            | 20            | 20            |
| Head available for system | m.w.g.<br>(ft.w.g.) | 5<br>(16.2)   | 4.5<br>(14.7) | 3.3<br>(10.8) | 1.9<br>(6.2)  |
| With Ideal System         | m.w.g.              | 4.9           | 4.3           | 3.0           | 1.5           |
| Filter & Valves           | (ft.w.g.)           | 16            | 14.1          | 9.8           | 4.9           |

### 5. Filling

The system may be filled by the following method:

Where the mains pressure is excessive a pressure reducing valve must be used to facilitate filling.

- Thoroughly flush out the whole system with cold water.
- Fill and vent the system until the pressure gauge registers 1 bar and examine for leaks
- Check that a 15 mm diameter pipe is correctly located and secured (using the clip supplied)
- Check the operation of the PRV by raising the water pressure until the valve lifts. This should occur within 0.3 bar of the preset lift pressure.
- Check no escape of water occurs except at the discharge point
- Release water from the system until the minimum system design pressure is reached; 1.0 bar if the system is to be pre-pressurised.

### 1.16 SYSTEM BALANCING

**Note.** Systems incorporating zone valves which could completely cut off the flow through the system must also include a bypass.

The boiler does not normally need a bypass but at least some radiators on the heating circuit, of load of at least 10% of the minimum boiler output, must be provided with twin lockshield valves so that this minimum heating load is always available.

#### Balancing

1. Set the programmer to ON.

Close the manual or thermostatic valves on all radiators, leaving the twin lockshield valves (on the radiators referred to above) in the OPEN position.

Turn up the room thermostat and adjust the lockshield valve to give an uninterrupted flow through the radiator.

These valves should now be left as set.

2. Open all manual or thermostatic radiator valves and adjust the lockshield valves on the remaining radiators, to give around 20°C temperature drop at each radiator.
3. Adjust the room thermostat and programmer to NORMAL settings.

### 1.17 WATER TREATMENT

#### Central Heating

The Logic range of boilers have an ALUMINIUM alloy heat exchanger.

 **IMPORTANT** The application of any other treatment to this product may render the guarantee of Ideal Heating invalid.

**The Ideal System Filter will aid against the build up of iron oxide debris, however the below water treatment is also recommended by Ideal Heating.**

**Ideal Heating** recommend Water Treatment in accordance with the Benchmark Guidance Notes on Water Treatment in Central Heating Systems.

If water treatment is used **Ideal Heating** recommend only the use of SCALEMASTER SM-1 PRO, FERNOX, MBI, ADEY MC1, SENTINEL X100 or CALMAG CM100 inhibitors and associated water treatment products, which must be used in accordance with the manufacturers' instructions.

This boiler can be used with a water softener. However, the heating system should not be filled with softened water as any softening chemicals could enhance corrosion of certain materials in the heating system, including aluminium and steel. The heating system should always be filled from the bypass on the water softener installation.

#### Notes

1. It is most important that the correct concentration of the water treatment products is maintained in accordance with the manufacturers' instructions.
2. If the boiler is installed in an existing system any unsuitable additives **MUST** be removed by thorough cleansing. BS7593:2019 details the steps necessary to clean a domestic heating system.
3. In hard water areas, treatment to prevent lime scale may be necessary - however the use of artificially softened water is **NOT** permitted.
4. Under no circumstances should the boiler be fired before the system has been thoroughly flushed.

For further information contact:

Fernox  
[www.fernox.com](http://www.fernox.com)  
Tel: +44 (0) 3301 007750

Sentinel Performance Solutions  
[www.sentinelprotects.com](http://www.sentinelprotects.com)  
Tel: +44 (0) 1928 704330

Scalemaster Water Treatment Products  
[www.scalemaster.co.uk](http://www.scalemaster.co.uk)  
Tel: +44 (0) 1785 811636

Calmag Ltd.  
[www.calmag Ltd.com](http://www.calmag Ltd.com)  
Tel: +44 (0) 1535 210320


Adey  
[www.adey.com](http://www.adey.com)  
Tel: +44 (0) 1242 546700

## Section 2 - Installation

### 2.1 BOILER ASSEMBLY - EXPLODED VIEW

|     |                         |     |                       |     |                              |     |                            |
|-----|-------------------------|-----|-----------------------|-----|------------------------------|-----|----------------------------|
| 104 | CH Return Valve         | 131 | Water Pressure Switch | 224 | Flue Manifold Top            | 325 | Control Box Front          |
| 105 | CH Flow Valve           | 135 | Pressure Gauge        | 227 | Clamp Retaining Flue Turret  | 326 | Blank Insert               |
| 108 | Pump Head               | 203 | Gas Cock              | 228 | Hose Condensate Internal     | 401 | Heat Engine                |
| 110 | Auto Air Vent           | 205 | Gas Valve             | 229 | Condensate Trap              | 503 | Wall Mounting Bracket      |
| 113 | Pressure Relief Valve   | 206 | Pipe - Gas Injector   | 231 | Condensate Outlet Connection | 504 | Front Panel                |
| 114 | Pipe - PRV Outlet       | 211 | Injector Assy         | 239 | Condensate Drain Tube        | 505 | Fascia                     |
| 115 | Pipe - Flow             | 214 | Venturi               | 302 | PCB                          | 506 | Bracket - Spark Generator  |
| 116 | Pipe - Return           | 215 | Fan                   | 306 | Ignition/Detection Electrode | 507 | Bracket - Expansion Vessel |
| 117 | Pipe - Expansion Vessel | 217 | Burner                | 308 | Ignitor Unit                 |     |                            |
| 118 | Expansion Vessel        | 218 | Gasket - Burner       | 309 | Thermistor                   |     |                            |
| 119 | Return Group Manifold   | 219 | Sump Clean Out Cover  | 313 | Ignition Lead                |     |                            |
| 120 | Flow Group Manifold     | 223 | Flue Manifold         | 324 | Control Box Lid              |     |                            |

**Note** that item numbers are linked to the spares list




## 2.2 UNPACKING

The boiler is supplied fully assembled in Pack A. A telescopic or non-telescopic flue assembly for rear or side flue outlet in Pack B is supplied as a separate order.

### Pack A Contents

1. Boiler
2. Hardware Pack Box
3. Wall Mounting Plate
4. These Installation/Users Instructions
5. Wall Mounting Template
6. Boiler Warranty
7. PRV Drain Pipe
8. Ideal System Filter


### Unpack and check the contents



### Hardware Pack


#### Box Contents

9. 1x HP Box - 180 x 111 x 57.5 mm
10. 2x Pipe CH Flow/Return
11. 1x Gas Cock
12. 2x Valve CH G<sup>3</sup>/<sub>4</sub> x 22 mm
13. 1x Pipe Gas Inlet
14. 1x PRV Clip





#### Accessory Bag Contents

15. 3x Washers\*
16. 2x Wall Plugs
17. 2x Screws
18. 1x Flue Clamp Screw



**IMPORTANT** This clip needs to be fitted to ensure correct operation of the boiler.

Refer to Section 2.17




\*Refer to Valve Washer Template inside box lid.

### 2.3 WALL MOUNTING TEMPLATE

**IMPORTANT:** Ensure the wall where the boiler will be is flat.

The wall mounting template is located on the internal protective packaging. The template shows the position of the fixing and rear flue centre holes for a standard installation.


1. Secure the template into the required position. Ensure it is square by hanging a plumbline.
2. If fitting a side flue, extend the flue centreline onto the side by **155 mm** on a standard wall fix or **200 mm** if using a stand-off bracket.
3. Mark the following on to the wall:
  - a. The selected group of wall mounting screw holes.
  - b. The centre position of the flue duct. Marking both the centre and the circumference of the flue duct.
4. Remove the template plate from the wall.



### 2.4 PREPARING THE WALL

**WARNING:** Ensure that, during the cutting operation, masonry falling outside of the building does not cause damage or personal injury.


1. Check all of the hole positions before drilling.
2. Cut the flue hole with a 127 mm core boring tool, ensure the hole is square to the wall.
3. Drill the 2 mounting holes with a 7.5 mm / 8 mm masonry drill and insert the plastic plugs provided.
4. Locate 2 No.14 x 50 mm screws in the wall mounting plate (one at each side, in any of the 3 holes provided at each side) and screw home. Ensure mounting bracket is level.



### 2.5 FITTING THE WALL MOUNTING PLATE


Screw the wall mounting plate to the wall using 2 wall plugs fitted previously with the 2 screws provided.

Choose one of the 2 sets of slots in left and right bank. Ensure that at least one of the screws is fitted into a top slot and the mounting bracket is level.














### 2.6 MOUNTING THE BOILER

1. Lift the boiler onto the wall mounting plate and locate it over the 2 tabs.



## 2.7 FLUES AND LOCATIONS

This installation & servicing manual must be read in conjunction with flue kit and fitting guide.


|                                                                                                                                                                                              |                                                                                                                                                                                   |                                                                                                                                                                                                    |                                                                                                                                                     |                                                                                                                                                                  |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p>Telescopic horizontal flue<br/>0.5 or 0.7 m</p>  <p>Ideal part no.<br/>0.5 m 208169<br/>0.7 m 208174</p> | <p>Horizontal flue<br/>0.6 or 0.8 m</p>  <p>Ideal part no.<br/>0.6 m 208171<br/>0.8 m 217442</p> | <p>Flue extension<br/>0.5 m, 1 m or 2 m</p>  <p>Ideal part no.<br/>0.5 m 211037<br/>1 m 203129<br/>2 m 211038</p> | <p>Flue deflector</p>  <p>Ideal part no.<br/>208176</p>           | <p>Vertical flue terminal and connector</p>  <p>Ideal part no.<br/>211039</p> |
| <p>Flue elbow 90°</p>  <p>Ideal part no.<br/>203130</p>                                                     | <p>Flue elbow 45°</p>  <p>Ideal part no.<br/>203131</p>                                          | <p>Weather collar pitched roof</p>  <p>Ideal part no.<br/>152258</p>                                              | <p>Weather collar flat roof</p>  <p>Ideal part no.<br/>152259</p> |                                                                                                                                                                  |
| <p>Balcony flue kit</p>  <p>Ideal part no. 208177</p>                                                     | <p>Soffit kit</p>  <p>Ideal part no. 211302</p>                                               | <p>Raised horizontal flue kit</p>  <p>Ideal part no. 208290</p>                                               |                                                                                                                                                     |                                                                                                                                                                  |

### WARNING:


- It is critical that products of combustion cannot re-enter the building.
- The flue terminal must always have a free passage of air.

### CAUTION:

- White sections of the flue must not be visible outside.
- Install a flue terminal guard where the flue terminal is less than 2 metres above a platform where persons can walk or come into contact with the terminal.
- Water is the only permitted lubricant for flue assembly.



## 2.8 FLUES AND LOCATIONS - CONTINUED



### B = Top Clearance

Top Clearance is measure from the top of the turret to the top of the hole where the flue terminates.

### L = Effective flue length.

The effective length of the flue is measured from the edge of the turret to the flue terminal lip.

Flue systems that require extension kits must be installed with a 1.5° decline from the flue terminal back to the boiler. A 1.5° decline can be achieved by designing the flue with a 26 mm rise per meter length of flue.

### ! IMPORTANT INFORMATION

Install the flue in accordance to BS 5440:1 2008

Position the terminal, so the products of combustion do not cause a nuisance.

The terminal outlet duct must not be closer than 25 mm to combustible material.

The flue is secured in the wall using either sand and cement or heatproof silicone.

The flue must be supported by a bracket every metre of flue length and at every change of direction. Concealed flues must have inspection hatches no more than 1.5 metres from joints.

Where possible inspection hatches should be located at change of directions. Where this is not possible then bends must be viewable from both sides.

Inspection hatches must be at least 300 mm<sup>2</sup>.


Table 4 - Flue Terminal Position

| Flue Terminal Positions                                                      | Min. Spacing*            |
|------------------------------------------------------------------------------|--------------------------|
| 1. Directly below, above or alongside an opening.                            | 300 mm                   |
| 2. Below guttering, drain pipes or soil pipes.                               | 75 mm<br>25 mm*          |
| 3. Below eaves.                                                              | 200 mm<br>25 mm*         |
| 4. Below balconies or a car port roof.                                       | 200 mm<br>25 mm*         |
| 5. From vertical drain pipes or soil pipes.                                  | 150 mm<br>25 mm*         |
| 6. From an internal or external corner or a boundary alongside the terminal. | 300 mm<br>25 mm*         |
| 7. Above adjacent ground, roof or balcony level.                             | 300 mm                   |
| 8. From a surface or a boundary facing the terminal.                         | 600 mm                   |
| 9. From a terminal facing a terminal.                                        | 1200 mm                  |
| 10. From an opening in a car port into dwelling.                             | 1200 mm                  |
| 11. Vertically from a terminal on the same wall.                             | 1500 mm                  |
| 12. Horizontally from a terminal wall.                                       | 300 mm                   |
| 13. Horizontally from an adjacent window                                     | 600 mm                   |
| 14. Facing an opening into an adjacent building                              | 2000 mm                  |
| 15. At an angle to the boundary                                              | 90° 300 mm<br>45° 600 mm |
| 16. Parallel to a boundary                                                   | 300 mm                   |
| 17. Below ground level – open light well                                     |                          |
| a) Below ground                                                              | <1,000 mm                |
| b) Above floor level                                                         | 300 mm                   |
| c) From side                                                                 | 300 mm                   |
| d) From facing surface                                                       | 600 mm                   |

\*Only one reduction down to 25mm is allowed per installation.


| Horizontal                                                                                                   | Maximum Effective Flue Length |
|--------------------------------------------------------------------------------------------------------------|-------------------------------|
| 24 kW                                                                                                        | 9.0 metres                    |
| 30 kW                                                                                                        | 8.0 metres                    |
| 35 kW                                                                                                        | 6.0 metres                    |
| Vertical                                                                                                     |                               |
| 24/30/35 kW                                                                                                  | 7.5 metres                    |
| Elbows increase resistance and have an effective flue length equivalence. The following table is an example. |                               |
| Part                                                                                                         | Resistance                    |
| 45° elbow                                                                                                    | 0.6 metres                    |
| 90° elbow                                                                                                    | 1.0 metres                    |

## 2.9 HORIZONTAL FLUE POSITIONS



Refer to Table 4

## 2.10 VERTICAL FLUE POSITIONS




Refer to Table 4

## 2.11 FLUE SYSTEM DIMENSIONS


### Flue Design

#### ! IMPORTANT:


1. Flue lengths may vary, always measure flue lengths before cutting.
2. Effective flue length and actual flue length are different measurements.
3. Effective flue length is made up of the flue length equivalence and the flue sections between the turret, elbows and terminal.
4. Actual flue length is the amount of flue needed to achieve the effective flue length, this includes insertions.



Turret insertion (mm)






Elbow insertion (mm)



| Part                | Actual Length | Insertion | Effective Length |
|---------------------|---------------|-----------|------------------|
| 1 m flue length     | 1000 mm       | 30 mm     | 970 mm           |
| 90° elbow           |               | n/a       | 1000 mm          |
| 1 m flue length     | 1000 mm       | 30 mm     | 970 mm           |
| 90° elbow           |               | n/a       | 1000 mm          |
| 0.6 m flue terminal | 600 mm        | 30 mm     | 570 mm           |
| Total               |               |           | 4.510 mm         |

## 2.12 FITTING THE TURRET


1. Ensure the condensate trap is filled with water
2. Ensure the rubber seal is not damaged and fitted correctly on the appliance manifold.
3. Firmly hold the flue and push the turret on until it has travelled 30 mm ensuring the flue has not rotated or moved forward.
4. Push the turret into the manifold ensuring the upper plastic lip is flush with the top of the manifold.
5. Fully engage the clamp location section into the manifold location hole and rotate down onto the flange.
6. Use the securing screws to secure the clamp to the appliance.
7. Ensure all sample points are accessible and all sample plugs and caps are fitted.



## 2.13 CUTTING THE FLUE


### CUTTING HORIZONTAL FLUE TERMINAL (non-telescopic)

1. Measure the required cut flue length ( $A + 44$  mm)
2. Measure from the outer terminal lip to the end of outer tube. Mark the required cut length ( $A + 44$  mm) around the circumference of the outer tube and cut following the mark to ensure it is cut square.
3. Mark and cut the inner tube 10 mm longer than the outer tube ensure the cut is square.
4. Remove all burrs on the inner and outer tube and place a light chamfer on the inner tube to aid with assembly.




### SETTING TELESCOPIC FLUE

1. Measure the required length ( $A + 44$  mm)
2. Pull flue apart until the desired length is achieved ensuring the stop mark is not visible.
3. Ensure both flue seams are at the top and the flue outlet terminal is uppermost.
4. Drill a 3.5 mm hole through the small and large outer tube using the pilot hole on the large outer tube.
5. Secure large and small outer tube using the screws provided.
6. Seal the joint on the out tube with the tape provided.
7. Fit the internal and external wall seals.



### FITTING THE FLUE THROUGH THE WALL (Internal Installation)

1. Measure the thickness of the wall.
2. To this measurement add 14 mm.
3. Make a mark on the flue shown as mark 1 (top right).
4. Make another mark on the flue a further 14 mm in shown as Mark 2 above right.
5. Fit the external wall seal (black) to the flue terminal ensuring it is fitted on the terminal outer lip seal.
6. Fit the inner wall seal approximately 65 mm prior to Mark 2.




7. Place the terminal end of the flue into the 127 mm core drilled centrally and slowly apply slight pressure and move the flue up or down or side to side. This will cause the external wall seal to fold in and allow the flue to pass through the wall.
8. When the inner wall seal is flush against the wall pull back the flue until Mark 1 is flush with the inner wall surface.
9. Hold the flue steady and push the inner wall seal towards the wall until Mark 2 is just visible.

### FITTING THE FLUE THROUGH THE WALL (External Installation)

1. Follow steps 1 - 5 from above.
2. Push the flue through the 127 mm core drilled hole from the outside
3. Return inside the property and fit the inner wall seal to the flue.
4. Pull the flue internally until Mark 1 is flush with the inner wall surface.
5. Holding the flue in this position push the inner wall seal towards the wall until Mark 2 is just visible.

If Mark 1 is not flush with the inner wall surface and can be seen prior to the wall surface, then the external wall seal will have been dislodged and will require to be re-fitted. If this situation occurs, then please start the process from the beginning.

On completion the flue will be correctly installed as below.



**IMPORTANT:** Ensure no White flue is visible between the flue terminal and the wall.

## Section 2 - Installation

A video showing how to correctly measure and fit a flue can be found by viewing the QR Code.

SCAN  
for Flue Fitting  
Video's



For the full range of  
FLUE AND ACCESSORIES  
please visit [idealheating.com/flues](http://idealheating.com/flues)

SCAN  
for Flues and  
Accessories Guide




### 2.14 ASSEMBLING THE VERTICAL FLUE

Determine the correct height that the flue should terminate above the roof. If after calculating or measuring the overall flue height from the top of the boiler, it is necessary to cut both pipes of assembly A, then ensure they are cut equally leaving the inner flue tube longer than the outer air tube as supplied.


Ensure the cut pipe ends are free from any burrs.

1. Position the roof flashing plate (supplied separately) over the hole cut in the roof and insert flue terminal from the roof end.
2. Fit the vertical connector (supplied in kit) in accordance with the instructions provided.
3. Secure the vertical connector by applying downward pressure on the connector.
4. Position the clamp on the top face of the flue manifold and push it horizontally backwards. Locate both clamp lugs into the flue manifold and secure to the flue manifold with the M5 retaining screw.



**Note.** Check the position of the inner flue duct relative to the outer duct on the assembled extension duct(s) and ensure the terminal flue duct is cut longer than the air duct to ensure engagement in the final flue duct seal.


7. Finally ensure the roof flashing plate is correctly sealed to the roof.




5. Push extension duct (if required (supplied separately)) into vertical connector.

**Note.** Ensure turret sample points are servicable and all caps and plugs are fitted. Fill the condensate trap/siphon with water.

6. If the last extension duct requires cutting, measure 'X', the distance (outer ducts), between the duct and the terminal and add 100 mm to this dimension. This gives the length of the last extension duct.



## 2.15 CONDENSATE DRAIN



This appliance is fitted with a siphonic 75 mm condensate trap system that requires filling before operating the appliance for the 1st time or after maintenance.

All condensate pipework should conform to the following:

- Where a new or replacement boiler is being installed, access to an internal 'gravity discharge' termination should be one of the main factors considered in determining boiler location.
- Plastic with push fit or solvent connections.
- Internal plastic pipe work a minimum of 19 mm ID (typically 22 mm OD).
- External plastic pipe must be a minimum of 30 mm ID (typically 32 mm OD) before it passes through the sleeved wall.
- All horizontal pipe runs must fall a minimum of 52 mm per metre away from the Boiler.
- External & unheated pipework should be kept to a minimum and insulated with Class "O" waterproof pipe insulation (UV Resistant).
- All installations must be carried out in accordance to the relevant connection methods as shown in the "Condensate installation diagrams" & BS6798.
- Pipework must be installed so that it does not allow spillage into the dwelling in the event of a blockage (through freezing)
- All internal burrs should be removed from the pipe work and any fittings.

In order to minimise the risk of freezing, terminate the condensate drainage pipe using one of the following methods:

### Internal Drain Connections

Route the condensate pipe by gravity to an internal, foul water discharge point.

Refer to Fig.  
1 & 2

### Condensate Pump

When it is not practical to terminate the condensate pipe to an internal foul water discharge point using gravity, use a suitable pump recommended by the boiler or pump manufacturer.

Refer to Fig.  
3

### External Drain Connections

The use of an externally run condensate drainage pipe should only be considered after exhausting all internal termination options as described previously. An external system must terminate at a suitable foul water discharge point or purpose designed soakaway. If an external system is chosen then the following measures must be adopted:

The external pipe run should be kept to a minimum using the most direct and "most vertical" route possible to the discharge point, with no horizontal sections in which condensate might collect.

- For connections to an external soil/vent stack. Insulation measures as described should be used.

Refer to Fig.  
4

- When a rainwater downpipe is used, an air break must be installed between the condensate drainage pipe and the downpipe to avoid reverse flow of rainwater into the boiler should the downpipe become flooded or frozen.

Refer to Fig.  
5

- Where the condensate drain pipe terminates in a purpose designed soakaway (see BS 6798) any above ground condensate drain pipe sections should be run and insulated as described above.

Refer to Fig.  
6

- Where the condensate drain pipe terminates over an open foul drain or gully, the pipe should terminate below the grating level, but above water level, to minimise "wind chill" at the open end. The use of a drain cover (as used to prevent blockage by leaves) may offer further prevention from wind chill.

### Unheated Internal Areas

Internal condensate drain pipes run in unheated areas, e.g. lofts basements and garages, should be treated as external pipe.

Ensure the customer is aware of the effects created by a frozen condensate and is shown where this information can be found in the user manual.

**Note.** Please check current HHIC condensate discharge guidance available via the Gas Safe Registered Technical Bulletins List.

continued . . . . .

## 2.16 CONDENSATE DRAIN - CONTINUED

**Figure 1** - Connection of Condensate Drainage Pipe to Internal Soil & Vent Stack




**Figure 2** - Connection of a Condensate Drainage Pipe Downstream of a Sink, Basin, Bath or Shower Water Trap to Internal Soil Vent Stack




**Figure 3** - Connection of a Condensate Pump Typical Method (see manufacturer's detailed instructions)




**Figure 4** - Connection of Condensate Drainage Pipe to External Soil & Vent Stack




**Figure 5** - Connection of a Condensate Drainage Pipe to an External Rainwater Downpipe (only combined foul/rainwater drain)





**Figure 6** - Connection of a Condensate Drainage Pipe to an External Purpose Made Soakaway.



## 2.17 CONNECTIONS & FILLING

**CAUTION:** Heating the isolation valves may damage the fibre seals

Remove all boss blanking plugs before connecting the hardware.

Fit each union with the fibre seals provided.

### WATER CONNECTIONS CH

1. Connect the CH flow service valve (black handle) and copper tail provided in the hardware pack to the threaded boss connection provided at the lower rear of the boiler.
2. Connect the CH return valve (black handle) and copper tail.


**IMPORTANT** Install the Ideal system filter according to system filter installation and maintenance guide. Failure to install the system filter correctly will affect boiler warranty.

### GAS CONNECTION

**CAUTION:** The gas service cock is sealed with a non-metallic blue fibre washer, which must not be overheated when making capillary connections.

For details of the position of the gas connection:

Refer to Gas Supply  
1.9



### FILLING

**IMPORTANT - when filling:**

- a. Ensure the dust cap on air vent located at the rear of the pump chamber is slightly unscrewed.
  - b. When filling, there may be a slight water leak from the air vent therefore electrical connections should be protected.
1. Ensure that the CH isolating handles are open.
  2. Fill and vent the system.
  3. Check for water soundness.

### PRV DRAIN

The PRV connection, located at the bottom left-hand side of the boiler, comprises an open ended grommet.

**IMPORTANT**

The grommet is designed for 15 mm Ø copper pipe.

If possible, preassemble and solder the pipework before installing.

If this is not possible the soldering must be more than 100 mm away from the grommet. Make sure the grommet is not damaged by the heat.

Install the condensate pipe as follows:

1. Make sure that the 15 mm Ø copper pipe is cut perpendicular to the pipe.
2. Make sure that the pipe is not damaged, and clean and free from burrs.
3. Using pliers put the clip over the grommet. Continue to hold the clip open.


**SCAN**  
for video




**Note.** Do not release the clip until step 5 (see below).

4. Push the copper pipe into the grommet (minimum of 15 mm). Make sure that the pipe is parallel with the grommet.
5. Below the stop mark on the grommet open the pliers to release the clip.
6. Make sure that the clip and pipe are attached correctly.
7. Make sure that the PRV discharge pipe is correctly attached. Make sure that the angle of the pipe run is sufficient to remove discharged water.

**WARNING:** Make sure that the water or steam (from the boiler) is discharged safely. Hot water or steam is dangerous and can cause serious injury, and damage to electrical systems.



A purpose made PRV drain pipe is provided with the boiler to allow safe discharge through a wall to the outside of the building. This is particularly relevant to 'high rise' installations but can be used for all installations.



## 2.18 ELECTRICAL CONNECTIONS

**WARNING:** This appliance must be earthed

A mains supply of 230 V ~ 50 Hz is required.

3 A fuse required. All external controls and wiring must be suitable for mains voltage.

Wiring external to the boiler must follow current I.E.E (BS7671) wiring regulations and local regulations.

Wiring should be 3 core PVC insulated cable, not less than 0.75 mm<sup>2</sup> (24 x 0.2 mm), and to BS 6500 Table 16.

Connection must be made in a way that allows complete isolation of the electrical supply. The means of isolation must be accessible to the user after installation.

## 2.19 INSTALLER WIRING

**WARNING:** Ensure the supply cord is not damaged

The boiler must be connected to a permanent live power supply.

### Connecting the Switched Live to the Boiler

1. Consult the Y Plan and S Plan diagrams overleaf.
2. Isolate the mains supply to the boiler
3. Remove the front panel.

Refer to Section 3.4

4. Swing down the control box into the service position, unclip and swing back the installer wiring cover and latch into the retaining clips.

All of the connections can now be readily accessed, the plugs can be removed to aid wiring.


5. Connect the switched live to the terminal block as shown.

**Note.** The cable strain relief system and grommets. Once any wiring is completed, to secure the boiler, reverse the order above.





### FROST THERMOSTAT – WIRING

If parts of the system are vulnerable to freezing or the programmer is likely to be left off during cold weather, a frost stat should be fitted in conjunction with a pipe thermostat..


#### Installer Connections (LHS)



#### Installer Connections (RHS)



### Logic Max System<sup>2</sup> S BOILER WITH Y PLAN SYSTEM (without outside sensor)





**Logic Max System<sup>2</sup> S BOILER WITH S PLAN SYSTEM (without outside sensor)**

Diagram of the rear of the unit showing the Strain Relief and the connection point for the power cord (6).

Wiring diagram for the EVOHOME CENTRAL CONTROLLER. The diagram shows a 230V 50Hz 3A FUSED power supply connected to terminals 1, 2, and 3 of a 10-terminal block. Terminal 1 is connected to the BLUE wire of the V4043H ZONE VALVE HTG MOTOR. Terminal 2 is connected to the BROWN wire of the V4043H ZONE VALVE HTG MOTOR. Terminal 3 is connected to the BLUE wire of the V4043H ZONE VALVE HW MOTOR. Terminal 4 is connected to the BROWN wire of the V4043H ZONE VALVE HW MOTOR. Terminal 5 is connected to the GAYELLOW wire of the HTG RECOVER BORG. Terminal 6 is connected to the BROWN wire of the HW RECOVER BORG. Terminal 7 is connected to the GAYELLOW wire of the HTG RECOVER BORG. Terminal 8 is connected to the BROWN wire of the HW RECOVER BORG. Terminal 9 is connected to the BLUE wire of the HTG RECOVER BORG. Terminal 10 is connected to the BROWN wire of the HW RECOVER BORG. A WIRELESS CYLINDER THERMOSTAT G004 is connected to terminals 1 and 2. A BOILER TRANSCEIVER is connected to terminals 1 and 2. A BOILER OPEN/THRM is connected to terminals 1 and 2.

27

## 2.23 WIRING DIAGRAM



## 2.24 COMMISSIONING AND TESTING

### A. Electrical Installation

**WARNING:** Electrical safety checks should be carried out by a qualified person.

Complete preliminary electrical system checks.

### B. Gas Installation

**WARNING:** Open windows, doors and extinguish flames before starting the next steps. Do not smoke.

1. The whole of the gas installation, including the meter, should be inspected and tested for tightness and purged in accordance with the recommendations of BS.6891.
2. Purge air from the gas installation by the approved methods only.

#### General

The combustion for this appliance has been checked, adjusted and preset at the factory for operation on the gas type defined on the appliance data plate.

**DO NOT** adjust the air/gas ratio valve.

Having checked:

- That the boiler has been installed in accordance with these instructions.
- The integrity of the flue system and the flue seals, as described in the Flue Installation section.

**Note.** Use the [INSTALLER APP] for fast, easy commissioning.

Proceed to put the boiler into operation as follows:

Check the operational (working) gas inlet pressure.


Set up the boiler to operate at maximum rate by opening hot tap to maximum flow.

Refer to Section  
2.29

With the boiler operating in the maximum rate condition check that the operational (working) gas pressure at the inlet gas pressure test point complies with the requirements.

Refer to Gas Supply  
page 10


Ensure that this inlet pressure can be obtained with all other gas appliances in the property working.



#### “SERVICE REQUIRED” function

When the boiler has run for more than 1 year the following screen will appear:-

Service Required





To cancel this message press “RESTART”.

**IMPORTANT:** A condition of the manufacturer's warranty is that Benchmark commissioning process is completed. The flow chart is provided on page 61.

## 2.25 INITIAL LIGHTING

### Legend

- A. Hot Keys
- B. Central Heating Temperature Knob
- C. Boiler Status Display
- D. Burner On indicator
- E. Pressure Gauge
- F. CH Flow Isolating Valve
- G. Gas Cock
- H. Gas Inlet Pressure Test point
- I. Boiler Drain Valve
- J. CH Return isolating valve



**CAUTION:** Do not operate the appliance before it has been fully vented of air. If it is necessary to operate the pump, do so with the gas service cock turned off.

The boiler incorporates a fan overrun cycle which must not be interrupted by isolation of electricity supply.

1. Check that the system has been filled and that the boiler is not airlocked. Ensure the automatic air vent cap is open.

2. Refit the boiler front panel.

Refer to Section  
3.4

3. Check that the drain valve (I) is closed and that the CH isolating valves (F & J) are OPEN.
4. Press the Mode button until OFF is shown underneath the boiler symbol on the boiler display.
5. Switch the electrical supply OFF
6. Check that the gas service cock (G) is OPEN.
7. Slacken the screw in the inlet pressure test point (H) and connect a gas pressure gauge via a flexible tube.
8. Switch the electricity supply ON and check all external controls are calling for heat.
9. Press the Mode Button (A) until OFF is not shown underneath the boiler symbol on the boiler display. Turn the Boiler Temperature Knob clockwise until a target of 80°C is shown. The boiler control will now go through its ignition sequence until the burner is established.

10. If the boiler does not light then after 5 attempts the boiler will lock out and display "Ignition Lockout". Press the Restart Button. The boiler will repeat its ignition sequence. If Restart occurs 5 times within 15 minutes then "Too Many Restarts" will be shown.

When the burner is established the flame symbol (D) will be shown on the display and the current flow temperature will be shown in the large digits underneath the radiator symbol.




11. Ensure that with the boiler operating, the dynamic gas pressure is able to obtain maximum output.

Refer to  
Table 1

**IMPORTANT** The gas input to the burner is regulated by the gas valve according to the air flow produced by the fan. It is NOT user-adjustable. Any interference to sealed settings on the gas valve will adversely affect operation and render our warranty void.

Refer to Gas Supply  
page 10

12. Remove gas pressure gauge, tighten inlet pressure test point and check for gas tightness.



Valves shown are in the open position.

## 2.26 USER INTERFACE COMMISSIONING

When the boiler is powered up for the first time, you will have the options to set the contact details for boiler servicing.



Set your contact details for boiler service?  
(defaults to Ideal Heating contact information otherwise)

---

No      Yes

## 2.27 CHANGING BOILER OPERATING MODE

The boiler mode is displayed by default, to change the mode, simply press mode and select the desired mode.

How to change operating mode from Boiler Off to Boiler On



**Off**  
To Switch On  
Press Mode Button

---

Menu      Mode

Press

### WITHOUT OUTSIDE SENSOR CONNECTED

On Mode, No Heat Demand



**Ready**  
Target 60°C  
Timer Off or Room Thermostat & Cylinder Thermostat Off

---

Menu      Mode

### WITH OUTSIDE SENSOR CONNECTED



**Off**  
To Switch On  
Press Mode Button & then  On



**Off**  
To Switch On  
Press Mode Button & then  On

---

Menu      Mode

| Off Mode                                                                                   | Summer Mode                                                                                  | Winter Mode                                                                                 |
|--------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------|
| <br>Off | <br>On  | <br>On |
| <br>Off | <br>Off | <br>On |

## 2.28 MENU OPERATION

The menu option contains a list of attributes that informs the user about the operating state of the boiler. The user should scroll down the menu and press enter to select the desired option.

Menu

→ Service Contact Name ←

Service Phone Number

Change Service Time

Exit Down Enter

Press

## 2.29 MAXIMUM AND MINIMUM RATES

Maximum and Minimum Rate can be accessed through the menu option.

Maximum Rate

Target Fan Speed: 6800rpm

Actual Fan Speed: 6800rpm

Time remaining: 10 mins

Exit

Press

The boiler will run at Maximum Rate for 10mins as long as there is sufficient cooling load

(With Outside Sensor)

Minimum Rate

Target Fan Speed: 1400rpm

Actual Fan Speed: 1400rpm

Time remaining: 10 mins

Exit

Press

The boiler will run at Minimum Rate for 10mins

If the return temperature is under 40°C then the fan will run for 30s at maximum rate before ramping down over 60s to minimum rate.


If the return temperature is above 40°C then the fan will ramp down over 60s to minimum rate.

## 2.30 GENERAL CHECKS


Make the following checks for correct operation in:

### CENTRAL HEATING (CH) MODE

1. Ensure that the CH external controls are calling for heat and the DHW external controls are not. The display should show:-



(No Outside Sensor)




(With Outside Sensor)


2. Gas Rate

Check the boiler gas rate when the boiler is at maximum output.  
Check at the gas meter, with no other appliance in use.  
Refer to Table 2.

3. Set the central heating external controls to OFF.  
The burner should go off.  
The display should show:-



(No Outside Sensor)



(With Outside Sensor)

4. Check the correct operation of the timer (if fitted) and all other system controls. Operate each control separately and check that the main burner responds.

### TEMPERATURE SETTING

#### (No Outside Sensor)

Temperature can be selected using the temperature knob (B).

| Knob Setting | Flow Temp (°C) |
|--------------|----------------|
| Max          | 80             |
| Min          | 30             |

### TEMPERATURE SETTING

#### (With Outside Sensor)

DHW Cylinder Flow Temperature is factory set to 80°C.

Nominal room temperature can be selected using the temperature knob (B).

CH Flow Temperature is automatically adjusted to give the desired nominal room temperature.

| Knob Setting | Flow Temp (°C) |
|--------------|----------------|
| Max          | 30             |
| Min          | 10             |

### WATER CIRCULATION SYSTEM

1. With the system cold, check that the initial pressure is correct to the system design requirements.  
For pre-pressurised systems, this should be 1.0 bar.
2. With the system hot, examine all water connections for soundness. The system pressure will increase with temperature rise but should not exceed 2.5 bar.
3. With the system still hot, turn off the gas, water and electricity supplies to the boiler and drain down to complete the flushing process.

**Note.** A flushing solution should be used during the flushing procedure. Flushing solutions: Fernox Superfloc, Sentinel X300 (new systems) or X400 (existing systems).

Refer to Section  
1.17

4. Refill and vent the system, add inhibitor, clear all air locks and again check for water soundness.

Refer to Section  
1.17

5. Reset the system initial pressure to the design requirement.

6. Balance the system.

Refer to Section  
1.16

7. Check the condensate drain for leaks and check that it is discharging correctly.

8. Finally, set the controls to the User's requirements.

The pump will operate briefly as a self-check once every 24 hours in the absence of any system demand.

## 2.31 RESTART PROCEDURE



**Ignition Lockout**


- 1 Check other gas appliances work.
- 2 Restart boiler.
- 3 If fault persists, contact installer.

Restart

Menu

Press

To restart the boiler, press the Restart button (A).



## 2.32 HANDING OVER

After commissioning the system, hand it over to the householder by the following actions:

1. Hand the Instructions to the householder and explain their responsibilities under the relevant national regulations.
2. Explain and demonstrate the lighting and shutting down procedures.
3. Explain how to operated the boiler and system controls.
4. Ensure the greatest possible fuel economy consistent with the household requirements of both heating and hot water consumption.
5. Explain the precautions necessary to prevent damage to the system and to the building, in the event of the system remaining inoperative during frosty conditions. .
6. Explain the function and the use of the boiler heating and domestic hot water controls.
7. Explain the function of the boiler fault mode.
8. Explain and demonstrate the function of timers and temperature controls, radiator valves etc., for the economic use of the system.
9. If a timer is fitted draw attention to the timer Users Instructions and hand them to the householder.
10. Explain that the dial behind the drop down door, indicates the central heating system pressure and that if the normal COLD pressure of the system is seen to decrease over a period of time then a water leak is indicated. Explain the re-pressurising procedure and if unable to re-pressurise or if the pressure continues to drop a registered local heating installer should be consulted.
12. After installation and commissioning please complete the Commissioning Checklist before handover to the customer.
13. A comprehensive service should be carried out annually.  
Stress the importance of regular servicing by a Gas Safe Registered Engineer.
14. Inform the householder of the boiler warranty and the requirement to register it to receive the full benefit.



Refer to  
Page 56

### ! IMPORTANT

Refer to Section  
2.17

11. Explain boiler restart procedure.

Refer to Section  
2.30

## 3.1 SERVICING SCHEDULE



**WARNING:** Servicing can only be carried out by Gas Safe Registered Engineers

Always turn OFF the gas supply at the gas service cock, and switch OFF and disconnect the electricity supply to the appliance before servicing

**Combustion testing must be carried out by a competent person using a combustion analyser conforming to BS EN 50379-3:2012.**

To ensure the continued safe and efficient operation of the appliance it is recommended that it is checked at regular intervals and serviced as necessary. The frequency of servicing will depend upon the installation condition and usage but should be carried out at least annually.

For the latest copy of literature, visit our website [idealheating.com](http://idealheating.com).

### PRELIMINARY INSPECTION

1. Light the boiler and carry out a pre-service check, refer to the fault finding chart.
2. Check the flue terminal (and terminal guard if fitted) for damage and obstruction.
3. Check combustion by connecting the flue gas analyser to the flue gas sampling point as shown in the diagram and measure CO and CO<sub>2</sub> at maximum rate. Set the boiler to Maximum and Minimum heat inputs.

Refer to Section  
3.13

If the CO / CO<sub>2</sub> ratio is greater than 0.004 please proceed to "Cleaning Procedure".

If the CO / CO<sub>2</sub> ratio is less than 0.004 please proceed to "Check Procedure".

### CHECK PROCEDURE

1. Check all water and gas joints for signs of leakage. Remake any suspect joints ensuring a gas tightness check is carried out if applicable and the water system is correctly refilled, vented and re-pressurised.
2. Proceed to "IMPORTANT".

### IMPORTANT

1. If, for any reason, the condensate trap has been removed, ensure the trap is refilled with water before re-assembling.
2. After completing the servicing or exchange of components always ensure all gas valve connections are gas tight with a gas soundness check up to the gas control valve.
3. When work is complete the front panel MUST be correctly refitted, ensuring that a good seal is made.
4. Clean the Ideal system filter, refer to system filter installation and maintenance guide for correct method of servicing.
5. Complete the service section in the Benchmark Commissioning Checklist.

### GENERAL


During Servicing, and after any maintenance or change of part of the combustion circuit, the following must be checked:

- The integrity of the flue system and the flue seals.
- The integrity of the boiler combustion circuit and the relevant seals.
- The operational (working) gas inlet pressure at maximum rate.
- The gas rate.
- The combustion performance.

### CLEANING PROCEDURE

1. Remove the casing.
2. Visually check the appliance for signs of leakage.
3. Remove the flue manifold.
4. Remove the fan.
5. Remove the burner.
6. Refit the sump outlet cover.
7. Clean the heat exchanger by pouring warm water across the whole heat engine to flush deposits taking care to avoid pouring water over the electrode.
8. Check the electrode for damage and clean using an abrasive cloth. Check and adjust the spark gap. Replace the electrode if damaged.
9. Clean out the sump outlet to ensure any debris is removed.
10. Remove and clean the condensate trap and re- prime the trap before re-installing.
11. Re-assemble the components in reverse order.
12. Clean the Ideal system filter. Refer to the system filter installation and maintenance guide for the correct method of servicing.
13. Carry out post service checks on the combustion circuit. See General below.
14. Check the system water quality in accordance with BS7593:2019.
15. Complete the service record in the Benchmark section.

**Do not operate the boiler if the front panel is not fitted.**



## 3.2 REMOVAL / REPLACEMENT OF COMPONENTS

**WARNING:** Do not operate the boiler without a front panel fitted

### When replacing any component.

1. Isolate the electricity supply.
2. Turn off the gas supply.
3. Remove the boiler front panel.

Refer to Section  
3.4

4. Swing the control box down into its servicing position.

### After removing / replacing any component.

5. Ensure all gas valve connections are gas tight with a gas soundness check up to the gas control valve.
6. Ensure all water connections are tight.
7. Test the appliance for correct and safe operation.

Refer to Section  
3.1 (General)

### Notes.

1. In order to assist fault finding, the control panel has an LCD diagnostic display. The key to boiler fault conditions is shown in Section 4.
2. In order to replace components in Sections 3.12, 3.14 and 3.3-3.25, it is necessary to drain the boiler.

Refer to Section  
3.3

## 3.3 DRAINING THE BOILER


Refer to Section  
3.2

### CENTRAL HEATING CIRCUIT

1. Close all the CH water isolating valves on both the flow and return.
2. To drain the primary heat exchanger circuit: Open the drain valve and attach a length of hose to the CH drain point.
3. After replacing any component on the boiler, remove the hose, close the drain valve and open all system isolating valves.
4. Repressurise before proceeding to check operation of the boiler.
5. Disconnect filling loop.

Refer to Section  
2.17


6. Check that the boiler operates.



## 3.4 BOILER FRONT PANEL REMOVAL / REPLACEMENT

### REMOVAL


1. Loosen the two screws retaining the front panel.
2. Pull the two clips down to disengage and pull panel forward and upward and remove.



View from bottom of boiler

### REPLACEMENT



3. Hook the panel onto the top retaining clips.
4. Push the panel until the 2 bottom spring clips engage ensuring the 1 knob and 4 buttons line up with the holes in the front panel.
5. Re-tighten the two retaining screws.



View from top of boiler






## 3.5 FLUE MANIFOLD REMOVAL/REPLACEMENT

1. Remove the two sump cover retaining screws
2. Remove the sump cover
3. Lift the manifold upwards to clear the sump
4. Move the manifold to the left and pull down to remove



## 3.6 FAN AND VENTURI ASSEMBLY REMOVAL AND CLEANING


1. Disconnect the electrical leads from the fan.
2. Remove the clip from the gas control valve outlet and ease the pipe upwards. Rotate and then ease down to remove.
3. Remove the extended nut on the fan mounting bracket.
4. Lift off fan and venturi assembly.
5. Undo the two M4 screws and release the nozzle assembly.
6. Inspect the injector for blockage or damage.
7. Clean the outside of the injector and use a small flue brush to clean the injector hole. Do not use anything abrasive such as a file.
8. Remove the screw and twist venturi anti-clockwise to remove venturi assembly, noting the orientation of the venturi in relation to the fan body.
9. Inspect fan outlet sealing gasket and replace if necessary.
10. Ensure the venturi is free from dust/debris.
11. Check the 'O'-rings are fitted correctly to the gas outlet pipe replacing if any damage is witnessed.




## 3.7 BURNER REMOVAL AND CLEANING

Refer to Section  
3.6


1. Remove the 2 burner front fixing screws and the 2 rear extended nuts.
2. Lift and pull forward the burner from the combustion chamber by holding the burner with two finger in the air inlet duct and your thumb on the top of the burner.
3. Tilt the burner towards yourself so that it raises to the vertical position.



4. Pull the burner out from the left hand side of the boiler once it is in the vertical position.



5. Carefully brush the ceramic burner with a soft non metallic bristle brush.



SCAN  
for video




SERVISING

## 3.8 CLEANING THE HEAT EXCHANGER


1. Replace the sump cover prior to the water flush process.
2. Thoroughly flush the heat exchanger by pouring water into the top of the combustion chamber ensuring the full surface of the heat exchanger is cleaned. Avoid pouring water over the electrode.
3. Remove the sump cover and clean loose deposits from the sump.

4. Inspect the ignition/detection electrode. Ensure that it is clean and in good condition - replace if necessary.
5. Check that the ignition gap is correct.

Refer to Section  
3.9



Combined Ignition Detection Electrode



### 3.9 IGNITION / DETECTION ELECTRODE REPLACEMENT / INSPECTION

Refer to Section  
3.2

1. Remove the fan.

Refer to Section  
3.6

2. Remove the flue manifold.

3. Remove the burner.

Refer to Section  
3.7

4. When servicing the boiler inspect the condition of the electrode and check the dimensions shown. If there is damage to the electrode continue to follow steps below for replacment.

5. Unplug the ignition lead from the electrode.


6. Remove the earth lead from the electrode.

7. Remove the 2 screws holding the electrode to the combustion chamber.


8. Remove the electrode.

9. Fit the new electrode, using the new gasket supplied. Check dimensions as shown.

Refer to Section  
2.30 & 2.31



Ignition /Detection  
Electrode





### 3.10 CLEANING THE CONDENSATE TRAP



**CAUTION:** Keep trap upright when removing

1. Pull off the rubber pipe at the sump drain.
2. Turn the trap clockwise to disengage and lift to remove.
3. Clean and fill trap with water.

SCAN  
for video



## 3.11 EXTERNAL SYSTEM FILTER CLEANING GUIDE


1. Switch off the boiler (isolate electrical supply).
2. Close the inlet/outlet valves. Remove magnet and vent.
3. Remove drain valve cap, open drain valve and vent.
4. Open inlet valve slowly and flush out filter until water runs clear.
5. Close the inlet valve. Close the drain valve.
6. Reinsert the magnet and replace the drain valve cap.
7. Open inlet/outlet valves, refill system and vent.
8. Restart the boiler.



**CAUTION:** Ensure that the magnet pocket is kept dry.



**IMPORTANT:** Repressurise the system after cleaning the filter, as loss of pressure will occur.



## 3.12 BURNER INJECTOR REPLACEMENT

Refer to Section  
3.6

## 3.13 BURNER REPLACEMENT

Refer to Section  
3.2 & 3.7



SCAN  
for video



## 3.14 RETURN THERMISTOR REPLACEMENT

1. Isolate and drain down the boiler.
2. Remove the clip from the pump housing and remove the thermistor.
3. Disconnect the electrical lead from the thermistor.
4. Reconnect the electrical lead to the new thermistor and reassemble, ensuring that the thermistor is fully engaged and the clip is correctly located.


Refer to Section  
3.2



## 3.15 SPARK GENERATOR REPLACEMENT

Refer to Section  
3.2

1. Disconnect the leads from the spark generator.
2. Gently push up the generator to release the bottom clip from the gas valve mounting bracket.
3. Lift the spark generator up and out of the bottom retaining location point.
4. Fit the new spark generator and reassemble, ensuring that the the earth lead is replaced.




## 3.16 GAS CONTROL VALVE REPLACEMENT

Refer to Section  
3.2

1. Disconnect and remove the trap and rubber connector.
2. Unplug the electrical lead connection from the gas control valve.
3. Remove the outlet gas valve clip and slide the pipe upwards.
4. Undo the gas inlet pipe union at the inlet to the gas valve.
5. Undo the two screws fixing the gas valve to the chassis base and lift the gas valve upwards.
6. Fit the new gas control valve ensuring that the 'O' ring and sealing washer are in place and reconnect gas and electrical connections.
7. Refit the trap.
8. Ensure all gas valve connections are gas tight with a gas soundness check up to the gas control valve.

Refer to Section  
3.17



## 3.17 CONDENSATE TRAP REPLACEMENT / CLEANING

Refer to Section  
3.2


## 3.18 PRESSURE GAUGE REPLACEMENT

Refer to Section  
3.2

1. Drain the boiler.


Refer to Section  
3.3

2. Remove the boiler front (see section 3.2), lower the control panel and remove the control box cover.
3. Ensuring there is no pressure in the system unclip the C clip from the flow pipe port and remove the capillary connection together with 'O' ring.



4. Releasing the two retaining clips on the pressure gauge ease the pressure gauge through the front of the control panel.
5. Fit the new pressure gauge from the front of the lower control panel ensuring correct orientation. Locate push fit connection into flow pipe ensuring 'O' ring in place and secure with the C clip.
6. Refill the boiler.

Refer to Section  
2.17



## 3.19 PRV REPLACEMENT

Refer to Section  
3.2

1. Drain the boiler.

Refer to Section  
3.3



2. Remove the trap and rubber pipe.
3. Pull out and remove the clip retaining the PRV.
4. Lift out the PRV/pipe assembly.
5. Remove the pipe and transfer to the new PRV.
6. Reassemble ensuring the retaining clip is correctly fitted.

SCAN  
for video



Refer to Section  
2.17

7. Check the operation of the PRV by raising the water pressure until the valve lifts. This should occur within 0.3 bar of the preset lift pressure.
8. Check no escape of water occurs except at the discharge point
9. Release water from the system until the minimum system design pressure is reached; 1.0 bar if the system is to be pre-pressurised.



## 3.20 PRIMARY PCB REPLACEMENT

**WARNING:** It is critical that the correct boiler size and fuel type is entered in to the boiler.

**CAUTION:** Fit the earth strap provided with the PCB to your wrist and secure to a suitable earth on the boiler chassis.

Refer to Section 3.2

1. Carefully release the four retaining clips and remove control box cover.
2. Unplug all lead connections to the PCB.
3. Spring out the four side retaining clips and pull the PCB upwards to clear the corner retaining posts.
4. Fit the new PCB.
5. Re-connect all plug connections.
6. Reassemble.
7. Turn power on, display shows:

|                       |
|-----------------------|
| Installer             |
| Initialise spare PCB? |
| Yes                   |

Press Yes and the following screen is shown:

|                     |
|---------------------|
| Select Boiler Brand |
| Option 1 of 4       |
| Max                 |
| Back Next Select    |

Press Next until 'Max' is shown, then press Select

|                        |
|------------------------|
| Select Boiler Name     |
| Option 1 of 4          |
| System <sup>2</sup> UK |

Press Next until 'System' UK is shown, then press Select

|                     |
|---------------------|
| Select Boiler Model |
| Option 1 of 6       |
| System UK           |
| 15kW                |
| Natural Gas         |
| Back Next Select    |



Press Next until correct Boiler model shown

- 1/6 System 15 NG
- 2/6 System 18 NG
- 3/6 System 18 Propane
- 4/6 System 24 NG
- 5/6 System 30 NG
- 6/6 System 30 Propane

Press Select to confirm & the following screen is shown:

|                     |
|---------------------|
| Program this model? |
| System UK           |
| 15kW                |
| Natural Gas         |
| Back Yes            |

Press Yes to finish.



## 3.21 PUMP AUTOMATIC AIR VENT REPLACEMENT

Refer to Section  
3.2

1. Drain the boiler.

Refer to Section  
3.3



2. Remove the expansion vessel.

Refer to Section  
3.25

3. Firstly, increase access area by disconnecting the 22 mm pipe connection at top of pump manifold and bottom of heat exchanger and remove pipe.
4. The automatic air vent head is retained in the pump body with a bayonet connection. The air vent head and float assembly is removed by turning the head anti-clockwise (viewed from above) and pulling upwards.

5. Reassemble. Ensure the air vent head 'o' ring seal is fitted.
6. Ensure the air vent cap is loose.
7. Refill the boiler. Check for leaks around the new air vent joint.

Refer to Section  
2.17



## 3.22 PUMP HEAD REPLACEMENT


Refer to Section  
3.2

1. Drain the boiler.

Refer to Section  
3.3

2. Disconnect the two electrical leads from the pump.
3. Remove the 4 allen screws retaining the pump head.
4. Remove the pump head.  
Be aware of water spillage.
5. Fit the new pump head.
6. Reassemble in reverse order.
7. Refill the boiler.

Refer to Section  
2.17



## 3.23 CH WATER PRESSURE SWITCH REPLACEMENT

Refer to Section  
3.2

1. Drain the boiler.


Refer to Section  
3.3

2. Pull off the two electrical connections.
3. Using a suitable tool, pull out the metal retaining clip.
4. Carefully withdraw the pressure switch.
5. Fit the new pressure switch and re-assemble in reverse order. Ensure the 'O' ring is fitted and replace clip.
6. Refill the boiler.

Refer to Section  
2.17

7. Check that the boiler operates..

Refer to Section  
2.30 & 2.32



## 3.24 FLOW THERMISTOR REPLACEMENT

Refer to Section  
3.2

1. Drain down the boiler.

Refer to Section  
3.3



2. Unplug the electrical lead.
3. Remove the clip from the flow pipe and remove the thermistor.
4. Fit the new thermistor, ensure 'O' ring is fitted and replace clip.

5. Reassemble.

6. Refill the boiler.

Refer to Section  
2.17

7. Check that the boiler operates.



## 3.25 EXPANSION VESSEL RECHARGING & REPLACEMENT

Refer to Section  
3.2

### RECHARGING

1. Remove the charge point cover.
2. Recharge the tank pressure to 0.75 bar.
3. Reassemble.
4. Check that the boiler operates.

### REPLACEMENT


5. Drain the boiler CH circuit.

Refer to Section  
3.3

6. Remove the retaining clip on the vessel water connection pipe and remove the pipe.
7. Support the expansion vessel and unscrew the 2 screws from the securing bracket, located on the top of the boiler, and remove.

Note the position of the bracket on the vessel

8. Remove the expansion vessel.
9. Fit the new expansion vessel.
10. Reassemble ensuring the 'O' ring seal is in place and refit the retaining clip.
11. Refill the boiler and check for leaks.



## 3.26 HEAT ENGINE REPLACEMENT

Refer to Section  
2.1

**CAUTION:** Protect the gas and electrical controls with a waterproof sheet.

Refer to Section  
3.2

1. Drain the boiler.

Refer to Section  
3.3

2. Undo the two screws and remove the sump cover retaining the lower flue manifold.
3. Lift the manifold to clear the bottom sealing gasket and remove manifold.
4. Remove the fan / venturi assembly and place on one side.

Refer to Section  
3.6

5. Remove the burner and place on one side.

Refer to Section  
3.7

6. Remove the ignition/detection electrode.

Refer to Section  
3.9

7. Remove the spark generator.

Refer to Section  
3.15

8. Remove the gas valve.

Refer to Section  
3.16

9. Remove the expansion vessel.

Refer to Section  
3.25

10. Remove the 2 M5 screws retaining the spark generator, mounting bracket and transfer bracket to the new heat exchanger.
11. Undo the pump union nut and remove pipe.
12. Remove the two retaining pipe clips and remove pipes.
13. Remove the condensate rubber pipe.

Refer to Section  
3.10

14. Remove the two heat exchanger fixing screws.
15. Remove the Heat exchanger, slide out of location bracket.
16. If replacement sump required: Rotate heat exchanger assembly 180°. Place new sump onto heat exchanger, ensuring correct orientation and seal is in place. Then gently apply pressure to the base of the sump at each tab fixing point and engage tabs onto the heat exchanger.
17. Reassemble, ensuring the heat exchanger is located correctly in the LHS retaining bracket. Replace any new 'O' rings supplied with new heat exchanger and replace gaskets or seals if any sign of damage is evident. When replacing the spring clips located on the return pipe connection, ensure clip is oriented to correctly match connecting pipe diametres.

18. Ensure the trap is filled with water.


Refer to Section  
3.17

19. Refill the boiler and check for leaks.

Refer to Section  
2.15


20. Ensure all gas valve connections are gas tight with a gas soundness check up to the gas control valve.

21. Check that the boiler operates.




## 4.1 MAIN MENU, FAULT HELP


Fault finding help can be accessed through the menu. Fault finding help lists all the common faults with the necessary checks. More detailed fault checks and actions are described in the following pages.




## 4.2 OVERHEAT LOCKOUT




## 4.3 IGNITION LOCKOUT




## 4.4 FLAME ON BEFORE GAS VALVE ON




## 4.5 LOW WATER PRESSURE




## 4.6 FLAME LOSS




## 4.7 FAN FAULT




## 4.8 FLOW THERMISTOR FAULT




## 4.9 RETURN THERMISTOR FAULT







## 4.10 OUTSIDE SENSOR FAULT




## 4.11 NO CH OPERATION



## 4.12 NO DHW OPERATION



## 4.13 NO DISPLAY



## Section 5 - Spare Parts

When replacing any part on this appliance use only spare parts that you can be assured conform to the safety and performance specification that we require. Do not use reconditioned or copy parts that have not been clearly authorised by Ideal.

Failure to do so could affect safety or performance of this appliance.

Comprehensive spares parts information and details of approved Ideal Parts Distributors are available on **idealparts.com**

**LINK**  
to spares



**Our Parts team are also available to help with your Ideal Spare Parts enquiries on 01482 498665.**

When calling, and to ensure we can provide you with the most accurate parts information, please ensure you have the following to hand;

- Boiler Model
- Appliance GC Number
- Boiler Serial Number

# Code Of Practice

For the installation, commissioning and servicing  
of domestic heating and hot water products

Benchmark places responsibilities on both manufacturers and installers.\* The purpose is to ensure that customers\*\* are provided with the correct equipment for their needs, that it is installed, commissioned and serviced in accordance with the manufacturer's instructions by competent persons and that it meets the requirements of the appropriate Building Regulations. Installers are required to carry out work in accordance with the following:

### Standards of Work

- Be competent and qualified to undertake the work required.
- Install, commission, service and use products in accordance with the manufacturer's instructions provided.
- Ensure that where there is responsibility for design work, the installation is correctly sized and fit for purpose.
- Meet the requirements of the appropriate Building Regulations. Where this involves notifiable work be a member of a Competent Persons Scheme or confirm that the customer has notified Local Authority Building Control (LABC), prior to work commencing.
- Complete all relevant sections of the Benchmark Checklist/Service Record when carrying out commissioning or servicing of a product or system.
- Ensure that the product or system is left in a safe condition and, whenever possible, in good working order.
- Highlight to the customer any remedial or improvement work identified during the course of commissioning or servicing work.
- Refer to the manufacturer's helpline where assistance is needed.
- Report product faults and concerns to the manufacturer in a timely manner.

### Customer Service

- Show the customer any identity card that is relevant to the work being carried out prior to commencement or on request.
- Give a full and clear explanation/demonstration of the product or system and its operation to the customer.
- Hand over the manufacturer's instructions, including the Benchmark Checklist, to the customer on completion of an installation.
- Obtain the customer's signature, on the Benchmark Checklist, to confirm satisfactory demonstration and receipt of manufacturer's instructions.
- Advise the customer that regular product servicing is needed, in line with manufacturers' recommendations, to ensure that safety and efficiency is maintained.
- Respond promptly to calls from a customer following completion of work, providing advice and assistance by phone and, if necessary, visiting the customer.
- Rectify any installation problems at no cost to the customer during the installer's guarantee period.



\*The use of the word "installer" is not limited to installation itself and covers those carrying out installation, commissioning and/or servicing of heating and hot water products, or the use of supporting products (such as water treatment or test equipment).

\*\*Customer includes householders, landlords and tenants.

© Heating and Hotwater Industry Council (HHIC)

[www.centralheating.co.uk](http://www.centralheating.co.uk)

# Benchmark Commissioning & Warranty Validation Service Record

It is a requirement that the boiler is installed and commissioned to the manufacturers' instructions and the data fields on the commissioning checklist completed in full.

To instigate the boiler warranty the boiler needs to be registered with the manufacturer within one month of the installation. The warranty rests with the end-user (consumer), and they should be made aware it is ultimately their responsibility to register with the manufacturer, within the allotted time period.

It is essential that the boiler is serviced in line with the manufacturers' recommendations, at least annually. This must be carried out by a competent Gas Safe registered engineer. The service details should be recorded on the Benchmark Service and Interim Boiler Work Record and left with the householder. Failure to comply with the manufacturers' servicing instructions and requirements will invalidate the warranty.



[www.hhic.co.uk](http://www.hhic.co.uk)

**This Commissioning Checklist is to be completed in full by the competent person who commissioned the boiler as a means of demonstrating compliance with the appropriate Building Regulations and then handed to the customer to keep for future reference.**

Failure to install and commission according to the manufacturers' instructions and complete this Benchmark Commissioning Checklist will invalidate the warranty. This does not affect the customer's statutory rights.

\* All installations in England and Wales must be notified to Local Authority Building Control (LABC) either directly or through a Competent Persons Scheme. A Building Regulations Compliance Certificate will then be issued to the customer.

© Heating and Hotwater Industry Council (HHIC)



[www.centralheating.co.uk](http://www.centralheating.co.uk)

# Section 6 - Benchmark to Commissioning

## GAS BOILER SYSTEM COMMISSIONING CHECKLIST & WARRANTY VALIDATION RECORD

|                                                                                                                                                         |  |                                          |  |                    |                               |                    |                                                     |                                                        |  |
|---------------------------------------------------------------------------------------------------------------------------------------------------------|--|------------------------------------------|--|--------------------|-------------------------------|--------------------|-----------------------------------------------------|--------------------------------------------------------|--|
| Address:                                                                                                                                                |  |                                          |  |                    |                               |                    |                                                     |                                                        |  |
| Boiler make and model:                                                                                                                                  |  |                                          |  |                    |                               |                    |                                                     |                                                        |  |
| Boiler serial number:                                                                                                                                   |  |                                          |  |                    |                               |                    |                                                     |                                                        |  |
| Commissioned by (PRINT NAME):                                                                                                                           |  |                                          |  |                    | Gas Safe registration number: |                    |                                                     |                                                        |  |
| Company name:                                                                                                                                           |  |                                          |  |                    | Telephone number:             |                    |                                                     |                                                        |  |
| Company email:                                                                                                                                          |  |                                          |  |                    | Company address:              |                    |                                                     |                                                        |  |
|                                                                                                                                                         |  |                                          |  |                    |                               |                    |                                                     | Commissioning date:                                    |  |
| Heating and hot water system complies with the appropriate Building Regulations? <span style="float: right;">Yes</span>                                 |  |                                          |  |                    |                               |                    |                                                     |                                                        |  |
| Optional: Building Regulations Notification Number (if applicable):                                                                                     |  |                                          |  |                    |                               |                    |                                                     |                                                        |  |
| Time, temperature control and boiler interlock provided for central heating and hot water <span style="float: right;">Yes</span>                        |  |                                          |  |                    |                               |                    |                                                     |                                                        |  |
| Boiler Plus requirements (tick the appropriate box(s))                                                                                                  |  |                                          |  |                    |                               |                    |                                                     |                                                        |  |
| Boiler Plus option chosen for combination boiler in ENGLAND                                                                                             |  |                                          |  |                    | Weather compensation          |                    | Smart thermostat with automisation and optimisation |                                                        |  |
|                                                                                                                                                         |  |                                          |  |                    | Load compensation             |                    | Flue Gas Heat Recovery                              |                                                        |  |
| Time and temperature control to hot water                                                                                                               |  | Cylinder thermostat and programmer/timer |  |                    |                               | Combination boiler |                                                     |                                                        |  |
| Zone valves                                                                                                                                             |  | pre-existing                             |  | Fitted             |                               | Not required       |                                                     |                                                        |  |
| Thermostatic radiator valves                                                                                                                            |  | pre-existing                             |  | Fitted             |                               | Not required       |                                                     |                                                        |  |
| Automatic bypass to system                                                                                                                              |  | pre-existing                             |  | Fitted             |                               | Not required       |                                                     |                                                        |  |
| Underfloor heating                                                                                                                                      |  | pre-existing                             |  | Fitted             |                               | Not required       |                                                     |                                                        |  |
| Water quality                                                                                                                                           |  |                                          |  |                    |                               |                    |                                                     |                                                        |  |
| The system has been flushed, cleaned and a suitable inhibitor applied upon final fill, in accordance with BS7593 and boiler manufacturers' instructions |  |                                          |  |                    |                               |                    |                                                     | Yes                                                    |  |
| What system cleaner was used?                                                                                                                           |  |                                          |  |                    | Brand:                        |                    |                                                     | Product:                                               |  |
| What inhibitor was used?                                                                                                                                |  |                                          |  |                    | Brand:                        |                    |                                                     | Product:                                               |  |
| Primary water system filter                                                                                                                             |  | pre-existing                             |  | Fitted             |                               | Not required       |                                                     |                                                        |  |
| CENTRAL HEATING MODE measure and record (as appropriate)                                                                                                |  |                                          |  |                    |                               |                    |                                                     |                                                        |  |
| Gas rate (for combination boilers complete DHW mode gas rate)                                                                                           |  |                                          |  | m <sup>3</sup> /hr |                               | or                 |                                                     | ft <sup>3</sup> /hr                                    |  |
| Central heating output left at factory settings?                                                                                                        |  |                                          |  | Yes                |                               |                    |                                                     | No                                                     |  |
| If no, what is the maximum central heating output selected?                                                                                             |  |                                          |  | kW                 |                               |                    |                                                     |                                                        |  |
| Dynamic gas inlet pressure                                                                                                                              |  |                                          |  | mbar               |                               |                    |                                                     |                                                        |  |
| Central heating flow temperature                                                                                                                        |  |                                          |  | °C                 |                               |                    |                                                     |                                                        |  |
| Central heating return temperature                                                                                                                      |  |                                          |  | °C                 |                               |                    |                                                     |                                                        |  |
| System correctly balanced/rebalanced?                                                                                                                   |  |                                          |  | Yes                |                               |                    |                                                     |                                                        |  |
| COMBINATION BOILERS ONLY                                                                                                                                |  |                                          |  |                    |                               |                    |                                                     |                                                        |  |
| Is the installation in a hard water area (above 200ppm)?                                                                                                |  |                                          |  | Yes                |                               |                    |                                                     | No                                                     |  |
| Water scale reducer/softener                                                                                                                            |  | pre-existing                             |  | Fitted             |                               | Not required       |                                                     |                                                        |  |
| What type of scale reducer/softener has been fitted?                                                                                                    |  |                                          |  | Brand:             |                               |                    | Product:                                            |                                                        |  |
| Water meter fitted?                                                                                                                                     |  |                                          |  | Yes                |                               |                    |                                                     | No                                                     |  |
| If yes- DHW expansion vessel                                                                                                                            |  | pre-existing                             |  | Fitted             |                               | Not required       |                                                     |                                                        |  |
| Pressure reducing valve                                                                                                                                 |  | pre-existing                             |  | Fitted             |                               | Not required       |                                                     |                                                        |  |
| DOMESTIC HOT WATER MODE Measure and record                                                                                                              |  |                                          |  |                    |                               |                    |                                                     |                                                        |  |
| Gas rate                                                                                                                                                |  |                                          |  | m <sup>3</sup> /hr |                               | or                 |                                                     | ft <sup>3</sup> /hr                                    |  |
| Dynamic gas inlet pressure at maximum rate                                                                                                              |  |                                          |  | mbar               |                               |                    |                                                     |                                                        |  |
| Cold water inlet temperature                                                                                                                            |  |                                          |  | °C                 |                               |                    |                                                     |                                                        |  |
| Hot water has been checked at all outlets                                                                                                               |  |                                          |  | Yes                |                               |                    |                                                     | Temperature °C                                         |  |
| CONDENSATE DISPOSAL                                                                                                                                     |  |                                          |  |                    |                               |                    |                                                     |                                                        |  |
| The condensate drain has been installed in accordance with the manufacturers' instructions and/or BS5546/BS6798                                         |  |                                          |  |                    |                               |                    |                                                     | Yes                                                    |  |
| Point of termination                                                                                                                                    |  |                                          |  | Internal           |                               |                    |                                                     | External (only where internal termination impractical) |  |
| Method of disposal                                                                                                                                      |  |                                          |  | Gravity            |                               |                    |                                                     | Pumped                                                 |  |
| ALL INSTALLATIONS                                                                                                                                       |  |                                          |  |                    |                               |                    |                                                     |                                                        |  |
| Record the following                                                                                                                                    |  | At max rate:                             |  | CO ppm             |                               | CO <sub>2</sub> %  |                                                     | CO/CO <sub>2</sub> Ratio                               |  |
|                                                                                                                                                         |  | At min rate (where possible)             |  | CO ppm             |                               | CO <sub>2</sub> %  |                                                     | CO/CO <sub>2</sub> Ratio                               |  |
| Where possible, has a flue integrity check been undertaken in accordance with manufacturers' instructions, and readings are correct?                    |  |                                          |  |                    |                               |                    |                                                     | Yes                                                    |  |
| The operation of the boiler and system controls have been demonstrated to and understood by the customer                                                |  |                                          |  |                    |                               |                    |                                                     | Yes                                                    |  |
| The manufacturers' literature, including Benchmark Checklist and Service Record, has been explained and left with the customer                          |  |                                          |  |                    |                               |                    |                                                     | Yes                                                    |  |
| Commissioning Engineer's signature                                                                                                                      |  |                                          |  |                    |                               |                    |                                                     |                                                        |  |
| Customer's signature<br>(To confirm satisfactory demonstration and receipt of manufacturers' literature)                                                |  |                                          |  |                    |                               |                    |                                                     |                                                        |  |

\* All installations in England and Wales must be notified to Local Authority Building Control (LABC) either directly or through a Competent Persons Scheme. A Building Regulations Compliance Certificate will then be issued to the customer.

© Heating and Hotwater Industry Council (HHIC)



www.centralheating.co.uk

## Section 6 - Benchmark to Commissioning

### SERVICE & INTERIM BOILER WORK RECORD

It is recommended that your boiler and heating system are regularly serviced and maintained, in line with manufacturers' instructions, and that the appropriate service / interim work record is completed.

#### Service provider

When completing a service record (as below), please ensure you have carried out the service as described in the manufacturers' instructions. Always use the manufacturers' specified spare parts.

|                                                                                                                                                    |                   |                           |                    |       |                    |
|----------------------------------------------------------------------------------------------------------------------------------------------------|-------------------|---------------------------|--------------------|-------|--------------------|
| <b>SERVICE/INTERIM WORK ON BOILER</b> delete as appropriate                                                                                        |                   |                           |                    | Date: |                    |
| Engineer name:                                                                                                                                     |                   | Company name:             |                    |       |                    |
| Telephone N°:                                                                                                                                      |                   | Gas Safe registration N°: |                    |       |                    |
| Max rate                                                                                                                                           | CO                | ppm                       | CO <sub>2</sub>    | %     | CO/CO <sub>2</sub> |
| Min rate                                                                                                                                           | CO                | ppm                       | CO <sub>2</sub>    | %     | CO/CO <sub>2</sub> |
| Where possible, has a flue integrity check been undertaken in accordance with manufacturers' instructions, and readings are correct?"              |                   |                           |                    |       | yes                |
| Gas rate:                                                                                                                                          | m <sup>3</sup> /h | OR                        | ft <sup>3</sup> /h |       |                    |
| Were parts fitted? delete as appropriate                                                                                                           |                   | Yes                       | No                 |       |                    |
| Parts fitted:                                                                                                                                      |                   |                           |                    |       |                    |
| System inhibitor concentration has been checked and appropriate action taken, in accordance with BS 7593 and boiler manufacturers' instructions. * |                   |                           |                    |       | n/a                |
| Comments:                                                                                                                                          |                   |                           |                    |       |                    |
| Signature:                                                                                                                                         |                   |                           |                    |       |                    |

\*A System inhibitor efficacy test is required on every annual service in accordance with the manufacturers' instructions and BS 7593. It is only acceptable to not have undertaken this if the service engineers attendance visit was in between annual services to attend a non-water facing component.

|                                                                                                                                                    |                   |                           |                    |       |                    |
|----------------------------------------------------------------------------------------------------------------------------------------------------|-------------------|---------------------------|--------------------|-------|--------------------|
| <b>SERVICE/INTERIM WORK ON BOILER</b> delete as appropriate                                                                                        |                   |                           |                    | Date: |                    |
| Engineer name:                                                                                                                                     |                   | Company name:             |                    |       |                    |
| Telephone N°:                                                                                                                                      |                   | Gas Safe registration N°: |                    |       |                    |
| Max rate                                                                                                                                           | CO                | ppm                       | CO <sub>2</sub>    | %     | CO/CO <sub>2</sub> |
| Min rate                                                                                                                                           | CO                | ppm                       | CO <sub>2</sub>    | %     | CO/CO <sub>2</sub> |
| Where possible, has a flue integrity check been undertaken in accordance with manufacturers' instructions, and readings are correct?"              |                   |                           |                    |       | yes                |
| Gas rate:                                                                                                                                          | m <sup>3</sup> /h | OR                        | ft <sup>3</sup> /h |       |                    |
| Were parts fitted? delete as appropriate                                                                                                           |                   | Yes                       | No                 |       |                    |
| Parts fitted:                                                                                                                                      |                   |                           |                    |       |                    |
| System inhibitor concentration has been checked and appropriate action taken, in accordance with BS 7593 and boiler manufacturers' instructions. * |                   |                           |                    |       | n/a                |
| Comments:                                                                                                                                          |                   |                           |                    |       |                    |
| Signature:                                                                                                                                         |                   |                           |                    |       |                    |

\*A System inhibitor efficacy test is required on every annual service in accordance with the manufacturers' instructions and BS 7593. It is only acceptable to not have undertaken this if the service engineers attendance visit was in between annual services to attend a non-water facing component.

|                                                                                                                                                    |                   |                           |                    |       |                    |
|----------------------------------------------------------------------------------------------------------------------------------------------------|-------------------|---------------------------|--------------------|-------|--------------------|
| <b>SERVICE/INTERIM WORK ON BOILER</b> delete as appropriate                                                                                        |                   |                           |                    | Date: |                    |
| Engineer name:                                                                                                                                     |                   | Company name:             |                    |       |                    |
| Telephone N°:                                                                                                                                      |                   | Gas Safe registration N°: |                    |       |                    |
| Max rate                                                                                                                                           | CO                | ppm                       | CO <sub>2</sub>    | %     | CO/CO <sub>2</sub> |
| Min rate                                                                                                                                           | CO                | ppm                       | CO <sub>2</sub>    | %     | CO/CO <sub>2</sub> |
| Where possible, has a flue integrity check been undertaken in accordance with manufacturers' instructions, and readings are correct?"              |                   |                           |                    |       | yes                |
| Gas rate:                                                                                                                                          | m <sup>3</sup> /h | OR                        | ft <sup>3</sup> /h |       |                    |
| Were parts fitted? delete as appropriate                                                                                                           |                   | Yes                       | No                 |       |                    |
| Parts fitted:                                                                                                                                      |                   |                           |                    |       |                    |
| System inhibitor concentration has been checked and appropriate action taken, in accordance with BS 7593 and boiler manufacturers' instructions. * |                   |                           |                    |       | n/a                |
| Comments:                                                                                                                                          |                   |                           |                    |       |                    |
| Signature:                                                                                                                                         |                   |                           |                    |       |                    |

\*A System inhibitor efficacy test is required on every annual service in accordance with the manufacturers' instructions and BS 7593. It is only acceptable to not have undertaken this if the service engineers attendance visit was in between annual services to attend a non-water facing component.

|                                                                                                                                                    |                   |                           |                    |       |                    |
|----------------------------------------------------------------------------------------------------------------------------------------------------|-------------------|---------------------------|--------------------|-------|--------------------|
| <b>SERVICE/INTERIM WORK ON BOILER</b> delete as appropriate                                                                                        |                   |                           |                    | Date: |                    |
| Engineer name:                                                                                                                                     |                   | Company name:             |                    |       |                    |
| Telephone N°:                                                                                                                                      |                   | Gas Safe registration N°: |                    |       |                    |
| Max rate                                                                                                                                           | CO                | ppm                       | CO <sub>2</sub>    | %     | CO/CO <sub>2</sub> |
| Min rate                                                                                                                                           | CO                | ppm                       | CO <sub>2</sub>    | %     | CO/CO <sub>2</sub> |
| Where possible, has a flue integrity check been undertaken in accordance with manufacturers' instructions, and readings are correct?"              |                   |                           |                    |       | yes                |
| Gas rate:                                                                                                                                          | m <sup>3</sup> /h | OR                        | ft <sup>3</sup> /h |       |                    |
| Were parts fitted? delete as appropriate                                                                                                           |                   | Yes                       | No                 |       |                    |
| Parts fitted:                                                                                                                                      |                   |                           |                    |       |                    |
| System inhibitor concentration has been checked and appropriate action taken, in accordance with BS 7593 and boiler manufacturers' instructions. * |                   |                           |                    |       | n/a                |
| Comments:                                                                                                                                          |                   |                           |                    |       |                    |
| Signature:                                                                                                                                         |                   |                           |                    |       |                    |

\*A System inhibitor efficacy test is required on every annual service in accordance with the manufacturers' instructions and BS 7593. It is only acceptable to not have undertaken this if the service engineers attendance visit was in between annual services to attend a non-water facing component.

|                                                                                                                                                    |                   |                           |                    |       |                    |
|----------------------------------------------------------------------------------------------------------------------------------------------------|-------------------|---------------------------|--------------------|-------|--------------------|
| <b>SERVICE/INTERIM WORK ON BOILER</b> delete as appropriate                                                                                        |                   |                           |                    | Date: |                    |
| Engineer name:                                                                                                                                     |                   | Company name:             |                    |       |                    |
| Telephone N°:                                                                                                                                      |                   | Gas Safe registration N°: |                    |       |                    |
| Max rate                                                                                                                                           | CO                | ppm                       | CO <sub>2</sub>    | %     | CO/CO <sub>2</sub> |
| Min rate                                                                                                                                           | CO                | ppm                       | CO <sub>2</sub>    | %     | CO/CO <sub>2</sub> |
| Where possible, has a flue integrity check been undertaken in accordance with manufacturers' instructions, and readings are correct?"              |                   |                           |                    |       | yes                |
| Gas rate:                                                                                                                                          | m <sup>3</sup> /h | OR                        | ft <sup>3</sup> /h |       |                    |
| Were parts fitted? delete as appropriate                                                                                                           |                   | Yes                       | No                 |       |                    |
| Parts fitted:                                                                                                                                      |                   |                           |                    |       |                    |
| System inhibitor concentration has been checked and appropriate action taken, in accordance with BS 7593 and boiler manufacturers' instructions. * |                   |                           |                    |       | n/a                |
| Comments:                                                                                                                                          |                   |                           |                    |       |                    |
| Signature:                                                                                                                                         |                   |                           |                    |       |                    |

\*A System inhibitor efficacy test is required on every annual service in accordance with the manufacturers' instructions and BS 7593. It is only acceptable to not have undertaken this if the service engineers attendance visit was in between annual services to attend a non-water facing component.

|                                                                                                                                                    |                   |                           |                    |       |                    |
|----------------------------------------------------------------------------------------------------------------------------------------------------|-------------------|---------------------------|--------------------|-------|--------------------|
| <b>SERVICE/INTERIM WORK ON BOILER</b> delete as appropriate                                                                                        |                   |                           |                    | Date: |                    |
| Engineer name:                                                                                                                                     |                   | Company name:             |                    |       |                    |
| Telephone N°:                                                                                                                                      |                   | Gas Safe registration N°: |                    |       |                    |
| Max rate                                                                                                                                           | CO                | ppm                       | CO <sub>2</sub>    | %     | CO/CO <sub>2</sub> |
| Min rate                                                                                                                                           | CO                | ppm                       | CO <sub>2</sub>    | %     | CO/CO <sub>2</sub> |
| Where possible, has a flue integrity check been undertaken in accordance with manufacturers' instructions, and readings are correct?"              |                   |                           |                    |       | yes                |
| Gas rate:                                                                                                                                          | m <sup>3</sup> /h | OR                        | ft <sup>3</sup> /h |       |                    |
| Were parts fitted? delete as appropriate                                                                                                           |                   | Yes                       | No                 |       |                    |
| Parts fitted:                                                                                                                                      |                   |                           |                    |       |                    |
| System inhibitor concentration has been checked and appropriate action taken, in accordance with BS 7593 and boiler manufacturers' instructions. * |                   |                           |                    |       | n/a                |
| Comments:                                                                                                                                          |                   |                           |                    |       |                    |
| Signature:                                                                                                                                         |                   |                           |                    |       |                    |

\*A System inhibitor efficacy test is required on every annual service in accordance with the manufacturers' instructions and BS 7593. It is only acceptable to not have undertaken this if the service engineers attendance visit was in between annual services to attend a non-water facing component.

\* All installations in England and Wales must be notified to Local Authority Building Control (LABC) either directly or through a Competent Persons Scheme. A Building Regulations Compliance Certificate will then be issued to the customer.

© Heating and Hotwater Industry Council (HHIC)



www.centralheating.co.uk

### FLOWCHART FOR CO LEVEL AND COMBUSTION RATIO CHECK ON COMMISSIONING A CONDENSING BOILER

#### Important Preliminary Information on Checks

The air gas ratio valve is factory-set and must not be adjusted DURING COMMISSIONING.

If the boiler requires conversion to operate with a different gas family (e.g. conversion from natural gas to LPG) separate guidance is provided with the conversion kit supplied and this must be followed.

#### PRIOR TO CO LEVEL AND COMBUSTION RATIO CHECK

The installation instructions must have been followed, gas type verified and gas supply pressure / gas rate checked as required prior to commissioning.

As part of the installation process, ESPECIALLY WHERE A FLUE HAS BEEN FITTED BY PERSONS OTHER THAN THE BOILER INSTALLER, visually check the integrity of the whole flue system to confirm that all components are correctly assembled, fixed and supported. Check that maximum flue lengths have not been exceeded and all guidance has been followed (e.g. Gas Safe Register Technical Bulletin (TB) 008 where chimney/flues are in voids).

The ECGA should be of the correct type, as specified by BS EN 50379-3:2012.

Prior to its use, the ECGA should have been maintained and calibrated as specified by the manufacturer. The installer must have the relevant competence for use of the analyser.

Check and zero the analyser IN FRESH AIR in accordance with the analyser manufacturer's instructions.

#### KEY:

**CO** = carbon monoxide

**CO<sub>2</sub>** = carbon dioxide


**O<sub>2</sub>** = oxygen

**Combustion Ratio** = The CO reading measured in ppm divided by the CO<sub>2</sub> reading first converted to ppm

**ppm** = parts per million

**GS(I&U)R** = Gas Safety (Installation and Use) Regulations

## Section 6 - Benchmark to Commissioning





At Ideal Heating we take our environmental impact seriously, therefore when installing any Ideal Heating product please make sure to dispose of any previous appliance in an environmentally conscious manner. Households can contact their local authority to find out how. See <https://www.gov.uk/managing-your-waste-an-overview> for guidance on how to efficiently recycle your business waste.

### Technical Training

Our Expert Academy offer a range of training options designed and delivered by our experts in heating. For details please visit: [expert-academy.co.uk](http://expert-academy.co.uk)

Ideal Boilers Ltd., pursues a policy of continuing improvement in the design and performance of its products. The right is therefore reserved to vary specification without notice.

Ideal is a trademark of Ideal Boilers.

Registered Office

Ideal Boilers Ltd., National Avenue, Hull, East Yorkshire, HU5 4JB

Tel 01482 492251 Fax 01482 448858

Registration No. London 322 137

EU Authorised Representative:

Atlantic SFDT

44 Boulevard des Etats-Unis, 85 000 La Roche-Sur-Yon, France

+33 (0)2 51 44 34 34

Ideal Technical Helpline: 01482 498663

Ideal Consumer Helpline: 01482 498660

Ideal Parts: 01482 498665

[idealheating.com](http://idealheating.com)

**ideal**  
HEATING